

# User's guide

## LD210



- Touch-screen process indicator for analogue encoders
- Two 16 bit analogue inputs -10/0 ... +10V, 0/4 ... 20mA
- Displays input 1, input 2 or a combination of the inputs (IN1+IN2, IN1-IN2, IN1xIN2, IN1/IN2)
- Digital, analogue, serial and relay outputs
- DC / AC power supply: 18÷30Vdc or 115÷230Vac

Suitable for the following models:

- LD210-P8-...
- LD210-PM-...

### General Contents

Preliminary information	10
1 - Safety summary	12
2 - Identification	14
3 - Mounting instructions	15
4 - Electrical connections	17
5 - Display and touch screen	26
6 - Menus and parameters	28
7 - Appendix	84
8 - Parameters / serial codes	85

This publication was produced by Lika Electronic s.r.l. 2019. All rights reserved. Tutti i diritti riservati. Alle Rechte vorbehalten. Todos los derechos reservados. Tous droits réservés.

This document and information contained herein are the property of Lika Electronic s.r.l. and shall not be reproduced in whole or in part without prior written approval of Lika Electronic s.r.l. Translation, reproduction and total or partial modification (photostat copies, film and microfilm included and any other means) are forbidden without written authorisation of Lika Electronic s.r.l.

The information herein is subject to change without notice and should not be construed as a commitment by Lika Electronic s.r.l. Lika Electronic s.r.l. reserves the right to make all modifications at any moments and without forewarning.

This manual is periodically reviewed and revised. As required we suggest checking if a new or updated edition of this document is available at Lika Electronic s.r.l.'s website. Lika Electronic s.r.l. assumes no responsibility for any errors or omissions in this document. Critical evaluation of this manual by the user is welcomed. Your comments assist us in preparation of future documentation, in order to make it as clear and complete as possible. Please send an e-mail to the following address [info@lika.it](mailto:info@lika.it) for submitting your comments, suggestions and criticisms.



# General contents

<b>General contents.....</b>	<b>3</b>
<b>Subject index.....</b>	<b>7</b>
<b>Typographic and iconographic conventions.....</b>	<b>9</b>
<b>Preliminary information.....</b>	<b>10</b>
Operational modes.....	10
Functional diagram.....	11
<b>1 - Safety summary.....</b>	<b>12</b>
1.1 Safety.....	12
1.2 Electrical safety.....	12
1.3 Mechanical safety.....	12
<b>2 - Identification.....</b>	<b>14</b>
<b>3 - Mounting instructions.....</b>	<b>15</b>
3.1 Overall dimensions.....	15
3.2 Installation.....	16
3.3 Cleaning, maintenance and service notes.....	16
<b>4 - Electrical connections.....</b>	<b>17</b>
4.1 DC power supply.....	17
4.2 AC power supply (-PM- order code).....	18
4.3 Auxiliary voltage output.....	18
4.4 Analogue inputs.....	19
4.4.1 Wiring of the analogue inputs.....	19
4.5 Reference output.....	20
4.5.1 Wiring of the reference output with potentiometer.....	20
4.6 Control inputs.....	21
4.6.1 Wiring of the control inputs.....	21
4.6.2 Note about mechanical switching contacts.....	21
4.7 Analogue output (-AVI- order code).....	22
4.8 Serial interface (-AVI- and -DO- order codes).....	23
4.9 Control outputs (-AVI- and -DO- order codes).....	24
4.9.1 Wiring of the control outputs.....	24
4.10 Relay outputs (-RO order code).....	25
4.10.1 Wiring of the relay outputs.....	25
<b>5 - Display and touch screen.....</b>	<b>26</b>
5.1 Screen structure for parametrization.....	26
5.2 Screen structure during operation.....	27
<b>6 - Menus and parameters.....</b>	<b>28</b>
6.1 Overview of the structure.....	28
6.2 General menu.....	34
<b>Operational mode.....</b>	<b>34</b>
<b>Pin preselection.....</b>	<b>34</b>
<b>Pin parameter.....</b>	<b>34</b>
<b>Back up memory.....</b>	<b>35</b>
<b>Factory settings.....</b>	<b>35</b>
6.3 IN 1 properties menu.....	36
<b>Configuration.....</b>	<b>36</b>
<b>Start value.....</b>	<b>36</b>

End value	36
Decimal point	36
Scale units	37
Sampling time (s)	38
Average filter	38
Offset	39
Linearization	39
Totalization	39
6.4 IN 1 linearization menu	40
P1(X)	40
P24(X)	40
P1(Y)	40
P24(Y)	40
6.4.1 Description of the linearisation function	40
6.5 IN 1 totalization menu	43
Time base	43
Divider	43
Decimal point	44
Scale units	44
6.6 IN 2 properties menu	46
Configuration	46
Start value	46
End value	46
Decimal point	46
Scale units	47
Sampling time (s)	48
Average filter	48
Offset	49
Linearization	49
Totalization	49
6.7 IN 2 linearization menu	50
P1(X)	50
P24(X)	50
P1(Y)	50
P24(Y)	50
6.7.1 Description of the linearisation function	50
6.8 IN 2 totalization menu	53
Time base	53
Divider	54
Decimal point	54
Scale units	54
6.9 Linkage properties menu	56
Factor	56
Divider	56
Additive value	56
Decimal point	57
Scale units	57
6.10 Preselection values menu	59
Preselection 1	59

<b>Preselection 2</b>	59
<b>Preselection 3</b>	59
<b>Preselection 4</b>	60
6.11 Preselection 1 menu	61
<b>Source 1</b>	61
<b>Mode 1</b>	61
<b>Hysteresis 1</b>	63
<b>Pulse time 1 (s)</b>	63
<b>Output target 1</b>	63
<b>Output polarity 1</b>	63
<b>Output lock 1</b>	64
<b>Start up delay 1 (s)</b>	64
<b>Event color 1</b>	64
6.12 Preselection 2 menu	65
<b>Source 2</b>	65
<b>Mode 2</b>	65
<b>Hysteresis 2</b>	65
<b>Pulse time 2 (s)</b>	65
<b>Output target 2</b>	65
<b>Output polarity 2</b>	65
<b>Output lock 2</b>	66
<b>Start up delay 2 (s)</b>	66
<b>Event color 2</b>	66
6.13 Preselection 3 menu	67
<b>Source 3</b>	67
<b>Mode 3</b>	67
<b>Hysteresis 3</b>	67
<b>Pulse time 3 (s)</b>	67
<b>Output target 3</b>	67
<b>Output polarity 3</b>	67
<b>Output lock 3</b>	68
<b>Start up delay 3 (s)</b>	68
<b>Event color 3</b>	68
6.14 Preselection 4 menu	69
<b>Source 4</b>	69
<b>Mode 4</b>	69
<b>Hysteresis 4</b>	69
<b>Pulse time 4 (s)</b>	69
<b>Output target 4</b>	69
<b>Output polarity 4</b>	69
<b>Output lock 4</b>	70
<b>Start up delay 4 (s)</b>	70
<b>Event color 4</b>	70
6.15 Serial menu	71
<b>Unit number</b>	71
<b>Serial baud rate</b>	71
<b>Serial format</b>	71
<b>Serial init</b>	72
<b>Serial protocol</b>	72

<b>Serial timer (s).....</b>	73
<b>Serial value.....</b>	73
<b>6.16 Analog OUT menu.....</b>	74
<b>Analog source.....</b>	74
<b>Analog format.....</b>	75
<b>Analog start.....</b>	75
<b>Analog end.....</b>	75
<b>Analog gain (%).....</b>	75
<b>Analog offset %.....</b>	76
<b>6.17 Command menu.....</b>	77
<b>Input 1 action.....</b>	77
<b>Input 1 config.....</b>	79
<b>Input 2 action.....</b>	79
<b>Input 2 config.....</b>	79
<b>Input 3 action.....</b>	79
<b>Input 3 config.....</b>	79
<b>6.18 Display menu.....</b>	80
<b>Start display.....</b>	80
<b>Source single.....</b>	80
<b>Source dual top.....</b>	81
<b>Source dual down.....</b>	81
<b>Color.....</b>	82
<b>Brightness.....</b>	82
<b>Contrast.....</b>	82
<b>Screen saver.....</b>	83
<b>Up-date-time.....</b>	83
<b>Font.....</b>	83
<b>7 - Appendix.....</b>	84
<b>7.1 Data readout via serial interface.....</b>	84
<b>8 - Parameters / serial codes.....</b>	85
<b>8.1 General menu.....</b>	85
<b>8.2 IN 1 properties menu.....</b>	85
<b>8.3 IN 1 linearization menu.....</b>	86
<b>8.4 IN 1 totalization menu.....</b>	87
<b>8.5 IN 2 properties menu.....</b>	88
<b>8.6 IN 2 linearization menu.....</b>	88
<b>8.7 IN 2 totalization menu.....</b>	90
<b>8.8 Linkage properties menu.....</b>	90
<b>8.9 Preselection values menu.....</b>	90
<b>8.10 Preselection 1 menu.....</b>	91
<b>8.11 Preselection 2 menu.....</b>	91
<b>8.12 Preselection 3 menu.....</b>	92
<b>8.13 Preselection 4 menu.....</b>	92
<b>8.14 Serial menu.....</b>	93
<b>8.15 Analog menu.....</b>	93
<b>8.16 Command menu.....</b>	94
<b>8.17 Display menu.....</b>	94
<b>8.18 Serial codes of commands.....</b>	95

# Subject index

<b>A</b>	
Additive value.....	56
Analog end.....	75
Analog format.....	75
Analog gain (%).....	75
Analog offset %.....	76
Analog source.....	74
Analog start.....	75
Average filter.....	38, 48
<b>B</b>	
Back up memory.....	35
Brightness.....	82
<b>C</b>	
Color.....	82
Configuration.....	36, 46
Contrast.....	82
<b>D</b>	
Decimal point.....	36, 44, 46, 54, 57
Divider.....	43, 54, 56
<b>E</b>	
End value.....	36, 46
Event color 1.....	64
Event color 2.....	66
Event color 3.....	68
Event color 4.....	70
<b>F</b>	
Factor.....	56
Factory settings.....	35
Font.....	83
<b>H</b>	
Hysteresis 1.....	63
Hysteresis 2.....	65
Hysteresis 3.....	67
Hysteresis 4.....	69
<b>I</b>	
Input 1 action.....	77
Input 1 config.....	79
Input 2 action.....	79
Input 2 config.....	79
Input 3 action.....	79
Input 3 config.....	79
<b>L</b>	
Linearization.....	39, 49
<b>M</b>	
Mode 1.....	61
Mode 2.....	65
Mode 3.....	67
Mode 4.....	69
<b>O</b>	
Offset.....	39, 49
Operational mode.....	34
Output lock 1.....	64
Output lock 2.....	66
Output lock 3.....	68
Output lock 4.....	70
Output polarity 1.....	63
Output polarity 2.....	65
Output polarity 3.....	67
Output polarity 4.....	69
Output target 1.....	63
Output target 2.....	65
Output target 3.....	67
Output target 4.....	69
<b>P</b>	
P1(X).....	40, 50
P1(Y).....	40, 50
P24(X).....	40, 50
P24(Y).....	40, 50
Pin parameter.....	34
Pin preselection.....	34
Preselection 1.....	59
Preselection 2.....	59
Preselection 3.....	59
Preselection 4.....	60
Pulse time 1 (s).....	63
Pulse time 2 (s).....	65
Pulse time 3 (s).....	67
Pulse time 4 (s).....	69
<b>S</b>	
Sampling time (s).....	38, 48
Scale units.....	37, 44, 47, 54, 57
Screen saver.....	83
Serial baud rate.....	71
Serial format.....	71
Serial init.....	72
Serial protocol.....	72
Serial timer (s).....	73
Serial value.....	73
Source 1.....	61
Source 2.....	65
Source 3.....	67
Source 4.....	69

Source dual down.....	81	Start value.....	36, 46
Source dual top.....	81	<b>T</b>	
Source single.....	80	Time base.....	43, 53
Start display.....	80	Totalization.....	39, 49
Start up delay 1 (s).....	64	<b>U</b>	
Start up delay 2 (s).....	66	Unit number.....	71
Start up delay 3 (s).....	68	Up-date-time.....	83
Start up delay 4 (s).....	70		

# Typographic and iconographic conventions

In this guide, to make it easier to understand and read the text the following typographic and iconographic conventions are used:

- parameters and objects both of the device and the interface are coloured in **GREEN**;
- alarms are coloured in **RED**;
- states are coloured in **FUCSIA**.

When scrolling through the text some icons can be found on the side of the page: they are expressly designed to highlight the parts of the text which are of great interest and significance for the user. Sometimes they are used to warn against dangers or potential sources of danger arising from the use of the device. You are advised to follow strictly the instructions given in this guide in order to guarantee the safety of the user and ensure the performance of the device. In this guide the following symbols are used:

	This icon, followed by the word <b>WARNING</b> , is meant to highlight the parts of the text where information of great significance for the user can be found: user must pay the greatest attention to them! Instructions must be followed strictly in order to guarantee the safety of the user and a correct use of the device. Failure to heed a warning or comply with instructions could lead to personal injury and/or damage to the unit or other equipment.
	This icon, followed by the word <b>NOTE</b> , is meant to highlight the parts of the text where important notes useful for a correct and reliable use of the device can be found. User must pay attention to them! Failure to comply with instructions could cause the equipment to be set wrongly: hence a faulty and improper working of the device could be the consequence.
	This icon is meant to highlight the parts of the text where suggestions useful for making it easier to set the device and optimize performance and reliability can be found. Sometimes this symbol is followed by the word <b>EXAMPLE</b> when instructions for setting parameters are accompanied by examples to clarify the explanation.

# Preliminary information

This guide is designed to provide the most complete information the operator needs to correctly and safely install and operate the **LD210 touch-screen indicator** series.

LD210 touch-screen indicator is designed to interface analogue encoders.

It is equipped with two 16-bit analogue inputs and connects current (0 ... 20 mA, 4 ... 20 mA) and voltage (-10 ... +10 V, 0 ... 10 V) analogue encoders. It can show process values from input 1 or input B and even the result of a variable combination of the inputs (sum, difference, ...). Among the available functions are tare, separate totalization, linearisation over 24 interpolation points, choice of the engineering unit, sampling time setting, etc.

It features a touch screen and 7-segment graphic display with a complete set of plain text, symbols and units. The LED display is bright and provides high contrast readability and also allows the background light to turn red, green or yellow in the event of the set occurrences such as when the threshold limits are exceeded. The combination of plain text and touch screen functions make the parametrization very user-friendly and intuitive.

In the series the following models are available:

- **LD210-P8** touch-screen indicator standard version;
- **LD210-PM** provides additional 115-230Vac power supply;
- **LD210-...-AVI** provides additional 16-bit analogue output, four control outputs and RS-232 / RS-485 serial interface;
- **LD210-...-DO** further offers four control outputs and RS-232 / RS-485 serial interface;
- **LD210-...-RO** is equipped with two relay outputs.

All options (-PM-, -AVI-, -DO-, -RO) can be freely combined.

For technical specifications please refer to the product datasheet.

To make it easier to read the text, this guide can be divided into two main sections.

In the first section (from section 1 to section 4) general information concerning the safety, the mechanical installation and the electrical connection.

In the second section (from section 5 to section 8) both general and specific information is given on the operator menu and the setup procedure.

## Operational modes


All functions can be configured in the parameter menu.

The device can be set to one of the following operation modes:

- **SINGLE** (only input A is used), see the **Operational mode** parameter in the "6.2 General menu" section on page 34.
  - Single channel operation of input 1

- **DUAL** (input A and input B are both used), see the **Operational mode** parameter in the "6.2 General menu" section on page 34.
  - Two channel operation of input 1 and input 2
- **IN 1 + IN 2** (input A and input B are both used), see the **Operational mode** parameter in the "6.2 General menu" section on page 34.
  - Two channel operation resulting from the addition of input 1 to input 2 (sum)
- **IN 1 – IN 2** (input A and input B are both used), see the **Operational mode** parameter in the "6.2 General menu" section on page 34.
  - Two channel operation resulting from the subtraction of input 2 from input 1 (difference)
- **IN 1 x IN 2** (input A and input B are both used), see the **Operational mode** parameter in the "6.2 General menu" section on page 34.
  - Two channel operation resulting from the multiplication of input 1 by input 2 (multiplication)
- **IN 1 / IN 2** (input A and input B are both used), see the **Operational mode** parameter in the "6.2 General menu" section on page 34.
  - Two channel operation resulting from the division of input 1 by input 2 (division)

## Functional diagram



## 1 - Safety summary



### 1.1 Safety

- Always adhere to the professional safety and accident prevention regulations applicable to your country during device installation and operation;
- installation and maintenance operations have to be carried out by qualified personnel only, with power supply disconnected and stationary mechanical parts;
- device must be used only for the purpose appropriate to its design: use for purposes other than those for which it has been designed could result in serious personal and/or the environment damage;
- high current, voltage and moving mechanical parts can cause serious or fatal injury;
- warning ! Do not use in explosive or flammable areas;
- failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the equipment;
- Lika Electronic assumes no liability for the customer's failure to comply with these requirements.



### 1.2 Electrical safety

- Turn OFF power supply before connecting the device;
- connect following to explanation in the "4 - Electrical connections" section on page 17;
- in compliance with 2014/30/EU norm on electromagnetic compatibility, following precautions must be taken:
  - before handling and installing the equipment, discharge electrical charge from your body and tools which may come in touch with the device;
  - power supply must be stabilized without noise; install EMC filters on device power supply if needed;
  - always use shielded cables (twisted pair cables whenever possible);
  - avoid cables runs longer than necessary;
  - avoid running the signal cable near high voltage power cables;
  - mount the device as far as possible from any capacitive or inductive noise source; shield the device from noise source if needed;
  - minimize noise by connecting the unit to ground (GND). Make sure that ground (GND) is not affected by noise. The connection point to ground can be situated both on the device side and on user's side. The best solution to minimize the interference must be carried out by the user.



### 1.3 Mechanical safety

- Install the device following strictly the information in the "3 - Mounting instructions" section;
- do not disassemble the unit;
- do not tool the unit;

- delicate electronic equipment: handle with care;
- do not subject the device to knocks or shocks;
- respect the environmental characteristics of the device.

## 2 - Identification

Device can be identified through the **order code** and the **serial number** printed on the label applied to its body. Information is listed in the delivery document too. Please always quote the order code and the serial number when reaching Ika Electronic for purchasing spare parts or needing assistance. For any information on the technical characteristics of the product, refer to the technical catalogue.



**Warning:** devices having order code ending with "/Sxxx" may have mechanical and electrical characteristics different from standard and be supplied with additional documentation for special connections (Technical info).

### 3 – Mounting instructions




#### WARNING

Installation and maintenance operations have to be carried out by qualified personnel only, with power supply disconnected and mechanical parts compulsorily in stop.

#### 3.1 Overall dimensions

Mount the display into the provided cut-out (w x h approx. 91 x 43 mm, 3.58" x 1.69") without panel clips.

Install panel clips on the display housing and screw until the unit is fixed.



Panel cut out: 91 x 43 mm (3.58" x 1.69")

### 3.2 Installation

The device is allowed to be installed and operated only within the permissible temperature range (-20°C +60°C / -4°F +140°F). Please ensure an adequate ventilation and avoid any direct contact between the device and gases / liquids. Before installation or maintenance, the unit must be disconnected from all voltage sources. Furthermore it must be ensured that no danger can arise in the event of contact with the disconnected voltage sources.

Devices which are supplied by AC voltages must be connected only by means of switches or circuit breakers with low voltage circuit. The switch or circuit breaker must be installed as near as possible to the device and further indicated as separator.

Incoming as well as outgoing wires and wires for extra low voltages (ELV) must be separated from dangerous electrical cables (SELV circuits) by using double or increased insulation.

All selected wires and insulations must comply with the provided voltage and temperature ranges. Furthermore all country and application specific standards which are relevant for structure, form and quality of the wires must be ensured. Indications about the permissible wire cross sections for wiring are described in the product datasheet.

Before starting the unit for the first time it must be ensured that all connections and wires are firmly plugged in and secured to the screw terminal blocks. All terminal blocks (including unused ones) must be fastened by turning the relevant screws clockwise up to the end position.

Overtvoltages at the connections must be limited to values in accordance with the overvoltage category II.

For placement, wiring, environmental conditions as well as shielding and earthing/grounding of the supply lines you must comply with the general standards stated for industrial automation industry and the specific shielding instructions provided by the manufacturer.

### 3.3 Cleaning, maintenance and service notes

To clean the unit please just use a slightly damp (not wet!), soft cloth. For the rear side no cleaning is necessary. For an unscheduled, individual cleaning of the rear side the maintenance technicians or installation operators are self-responsible.

During normal operation no maintenance is necessary. In case of unexpected problems, failures or malfunctions the device must be shipped back to the manufacturer for any checking, adjustment or repair (if necessary). Unauthorized opening and repair operations can have negative effects or cause failures to the protection measures of the unit.


## 4 – Electrical connections



### WARNING

Power supply must be turned off before performing any electrical connection!

The terminal block screws must be tightened using a slotted screwdriver having a 2 mm wide blade.



### 4.1 DC power supply

#### DC power supply technical specifications (-P8- order code)

Input voltage:	18Vdc ... 30Vdc
Protection circuit:	reverse polarity protection
Power consumption:	approx. 100 mA (unloaded)
Fuse protection:	external fuse T 0.5 A

The unit accepts DC supply from 18 to 30 V through terminal blocks 1 and 2. The power consumption depends on the level of the supply voltage (approx. 100 mA) and the additional current required by the Auxiliary Voltage output (3 – GND + 4 – Aux. Out, see the "4.3 Auxiliary voltage output" section on page 18).

All GND terminal blocks are internally connected.



### NOTE

For AC power supply (-PM- order code) see the following section.

## 4.2 AC power supply (-PM- order code)

### AC power supply technical specifications

Input voltage:	115Vac ... 230Vac (50÷60Hz)
Power consumption:	approx. 3 VA (unloaded)
Fuse protection:	external fuse T 0.1 A

The unit with -PM- order code also accepts AC power supply from 115 V to 230 V through terminal blocks 24 and 25. The power consumption depends on the level of the supply voltage (approx. 3 VA) and the additional current required by the Auxiliary Voltage output (3 – GND + 4 – Aux. Out, see the "4.3 Auxiliary voltage output" section below).

Devices with -PM- order code can also be supplied with a DC voltage between 18 V and 30 V through terminals 1 and 2, see the previous "4.1 DC power supply" section.

## 4.3 Auxiliary voltage output

### Auxiliary voltage output technical specifications

DC version:	Approx. 1 V lower than the power supply voltage
Output current:	max. 250 mA
AC version:	Approx. 24Vdc $\pm 15\%$
Output current:	150 mA up to 45°C / 80 mA when more than 45°C

Terminal blocks 3 and 4 provide an auxiliary output useful for supplying sensors and encoders.

The output voltage level depends on the power supply.

DC version	AC version
The encoder voltage is approx. 1 V lower than the power supply voltage at terminal blocks 1 and 2 and should be loaded with max. 250 mA.	The encoder voltage is 24 Vdc ( $\pm 15\%$ ) and should be loaded with max. 150 mA up to 45° Celsius. At higher temperature the maximum output current is reduced to 80 mA.

#### 4.4 Analogue inputs

##### Analogue inputs technical specifications

Number of inputs:	2
Configuration:	Current or voltage operation
Current input:	0 ... 20 mA / 4 ... 20 mA ( $R_i \approx 100 \text{ Ohm}$ )
Voltage input:	-10 ... +10 V / 0 ... +10 V ( $R_i \approx 50 \text{ kOhm}$ )
Resolution:	16 bits
Accuracy:	$\pm 0.1\%$

The unit provides two 16-bit analogue inputs through terminal blocks 6 and 7. The reference potential (AGND) for the analogue inputs is connected at terminal block 5.

The characteristics of the analogue inputs (voltage input or current input) can be set in the **IN 1 properties** and the **IN 2 properties** menus, see the "6.3 IN 1 properties menu" section on page 36 and the "6.6 IN 2 properties menu" section on page 46 respectively.




##### WARNING


The characteristics of the inputs (voltage level or current level) must be set before connecting the encoder!

##### 4.4.1 Wiring of the analogue inputs

###### Voltage input



###### Current input




## 4.5 Reference output

### Reference output technical specifications

Output voltage	10 V
Accuracy:	$\pm 0.1\%$
Load:	max. 10 mA

The unit provides a 10 V reference output through terminal block 8. The output should be loaded with max. 10 mA. This reference output can be used to connect a potentiometer.

#### 4.5.1 Wiring of the reference output with potentiometer



## 4.6 Control inputs


### Control inputs technical specifications

Number of inputs:	3
Format:	HTL, PNP (Low = 0 ... 3 V, High = 9 ... 30 V)
Frequency:	max. 10 kHz
Load:	max. 2 mA / $R_i > 15 \text{ k}\Omega$ / $470 \text{ pF}$

The three control inputs at terminal blocks 10, 11 and 12 have HTL PNP characteristics.

In the **Command** menu (see the "6.17 Command menu" section on page 77) the operation of the control inputs can be set. The available functions are: reset the display value, display switching, locking the touch screen or release the lock function of the control or relay outputs.

#### 4.6.1 Wiring of the control inputs



Unconnected control inputs are always "LOW".

All inputs are designed to receive impulses from an electronic impulse source.

#### 4.6.2 Note about mechanical switching contacts

When, exceptionally, mechanical contacts are used, please connect an external capacitor between GND (-) and the corresponding input (+). A capacity of  $10 \mu\text{F}$  will reduce the input frequency to 20 Hz and miscounting due to contact bouncing will be eliminated.



## 4.7 Analogue output (-AVI- order code)

### Analogue output technical specifications

Configuration:	Current or voltage operation
Voltage output (0):	-10 V ... +10 V (max. 2 mA)
Current output (1):	0 ... 20 mA (burden: max. 270 Ohm)
Current output (2):	4 ... 20 mA (burden: max. 270 Ohm)
Resolution:	16 bits
Accuracy:	$\pm 0.1\%$
Reaction time:	< 150 ms

A 16 bit analogue output is available through terminal blocks 13 and 14 / 15. It can be configured and scaled in the **Analog OUT** menu, see the "6.16 Analog OUT menu" section on page 74.

The following configurations are available (see the **Analog format** parameter on page 75):

- |          |                 |                 |
|----------|-----------------|-----------------|
| <b>0</b> | Voltage output: | -10 V ... +10 V |
| <b>1</b> | Current output: | 0 ... 20 mA     |
| <b>2</b> | Current output: | 4 ... 20 mA     |

The analogue output is proportional to the reference source and is referenced to potential AGND.

AGND and GND are internally connected.



### WARNING

Voltage and current outputs of the analogue output cannot be operated simultaneously.

#### 4.8 Serial interface (-AVI- and -DO- order codes)

##### Serial interface technical specifications

Format:	RS-232 (-AVI1- e -D01-) o RS-485 (-AVI2- e -D02-)
Baud rate:	9600, 19200 and 38400 baud


A serial interface (RS-232 / RS-485) is available through terminal blocks 16, 17 and 18.

It can be configured in the **Serial** menu, see the "6.15 Serial menu" section on page 71.


The RS-232 / RS-485 serial interface can be used:

- for easy setup and commissioning of the unit
- to modify settings and parameters during operation
- to read out internal states and current measuring values via PC or PLC

The following drawing shows the RS-232 connection to a PC by using a standard D-Sub 9-pin connector:



The following drawing shows the RS-485 connection to a PC by using a standard D-Sub 9-pin connector:



## 4.9 Control outputs (-AVI- and -DO- order codes)

### Control outputs technical specifications

Number of outputs:	4
Format / level:	5 ... 30 V (depending on the voltage level provided to terminal block 19 - COM+), PNP
Output current:	max. 200 mA
Reaction time:	< 1 ms


Four control outputs are available at terminal blocks 20, 21, 22 and 23 (+ terminal block 19 for switching voltage).

The switching conditions can be set in the **Preselection 1 ... Preselection 4** menus, see the "6.11 Preselection 1 menu" ... "6.14 Preselection 4 menu" sections on pages 61, 65, 67 and 69 respectively. The outputs "20 - Ctrl. Out 1", "21 - Ctrl. Out 2", "22 - Ctrl. Out 3" and "23 - Ctrl. Out 4" are fast PNP outputs with a switching capability of 5÷30 V / 200 mA per channel. The switching states are displayed (display with unit and status bar) as **C1** ... **C4**, see the "5 - Display and touch screen" section on page 26.

The switching voltage of the outputs must be applied to input terminal block 19 (COM+).

In case of switching inductive loads it is advisable to use an external filtering of the coils.

### 4.9.1 Wiring of the control outputs



## 4.10 Relay outputs (-RO order code)


### Relay outputs technical specifications

Number of outputs:	2
Configuration:	potential-free changeovers
AC switching capacity:	max. 250 Vac / 3 A / 750 VA
DC switching capacity:	max. 150 Vdc / 2 A / 50 W
Reaction time:	< 20 ms

Two relay outputs with potential-free changeover contacts are available at terminal blocks 27, 28, 29, 30, 31 and 32. The switching conditions can be set in the **Preselection 1 ... Preselection 4** menus, see the "6.11 Preselection 1 menu" ... "6.14 Preselection 4 menu" sections on pages 61, 65, 67 and 69 respectively. The switching states are displayed (display with unit and status bar) as **K1** and **K2**, see the "5 - Display and touch screen" section on page 26.

AC switching capacity max. 250 Vac / max. 3 A / 750 VA  
DC switching capacity max. 150 Vdc / max. 2 A / 50 W

#### 4.10.1 Wiring of the relay outputs



## 5 – Display and touch screen

### 5.1 Screen structure for parametrization

Menus and parameters are described in the "6 – Menus and parameters" section on page 28.



#### Start setup procedure

To enter the menus and edit the parameters, keep the touchscreen pressed for 3 seconds.



#### Selection of the menu

Select the menu by pressing the arrow keys and confirm the choice by pressing the **ok** key.

You can exit the selection of the menu by pressing the **C** key.



#### Selection of the parameter

Select the parameter by pressing the arrow keys and confirm the choice by pressing the **ok** key.

You can exit the selection of the parameter by pressing the **C** key.

#### Parameter setting:

After selection, the parameter (or its last digit) starts blinking. Set the parameter by pressing the **up** and **down** arrow keys, shift the cursor by pressing the **left** and **right** arrow keys and save the value by pressing the **ok** key.



You can exit the editing of the parameter by pressing the **C** key.

**Parameter changes become active only after closing the selection of the menu.**

## 5.2 Screen structure during operation

The following screens are available during operation. Depending on the device version and the selected operation mode, not all displays will be shown.

The sources (IN 1, IN 2 ...) for the single channel display and the two channel display are defined in the **Display** menu, see the "6.18 Display menu" section on page 80.



Single line display with unit and status bar

To switch to the next display, press the touch screen.

Control output states and relay states are only shown with AVI, DO and R0 order codes.



Two line display

To switch to the next display, press the top half of the screen.



Display for quick start of the preselection values setting process (see the "6.10 Preselection values menu" section on page 59)

To switch to the next display, press the top half of the screen or the **SKIP** key.

It is available only with AVI, DO and R0 order codes.



Display with current, minimum and maximum values of input 1 and input 2.

To switch to the next display, press the touch screen.

## 6 – Menus and parameters

### 6.1 Overview of the structure

The following tables offer an overview of the menus and their relevant parameters. The menu names are printed in bold and the associated parameters are listed under the menu name. Depending on the device model and the selected operation mode, only the available menus / parameters are shown.

**NOTE**

In the pages that describe the menus, the default values are highlighted with grey background.

<b>General menu</b> , see the "6.2 General menu" section on page 34
---

<b>Operational mode</b> , see on page 34
--

<b>Pin preselection</b> , see on page 34
--

<b>Pin parameter</b> , see on page 34
---------------------------------------

<b>Back up memory</b> , see on page 35
--

<b>Factory settings</b> , see on page 35
--

<b>IN 1 properties menu</b> , see the "6.3 IN 1 properties menu" section on page 36
---

<b>Configuration</b> , see on page 36
---------------------------------------

<b>Start value</b> , see on page 36
-------------------------------------

<b>End value</b> , see on page 36
-----------------------------------

<b>Decimal point</b> , see on page 36
---------------------------------------

<b>Scale units</b> , see on page 37
-------------------------------------

<b>Sampling time (s)</b> , see on page 38
---

<b>Average filter</b> , see on page 38
--

<b>Offset</b> , see on page 39
--------------------------------

<b>Linearization</b> , see on page 39
---------------------------------------

<b>Totalization</b> , see on page 39
--------------------------------------

It is only available if the **Linearization** parameter in the **IN 1 properties menu** (see on page 39) is set to either "1 – 1 QUADRANT" or "2 – 4 QUADRANT".

<b>IN 1 Linearization menu</b> , see the "6.4 IN 1 linearization menu" section on page 40
---

<b>P1(X)</b> , see on page 40
-------------------------------

...
-----

[P24\(X\)](#), see on page 40

[P1\(Y\)](#), see on page 40

...

[P24\(Y\)](#), see on page 40

It is only available if the **Totalization** parameter in the **IN 1 properties** menu (see on page 39) is set to "YES".

[IN 1 totalization menu](#), see the "6.5 IN 1 totalization menu" section on page 43

[Time base](#), see on page 43

[Divider](#), see on page 43

[Decimal point](#), see on page 44

[Scale units](#), see on page 44

It is only available if the **Operational mode** parameter in the **General** menu (see on page 34) is set to any dual channel mode.

[IN 2 properties menu](#), see the "6.6 IN 2 properties menu" section on page 46

[Configuration](#), see on page 46

[Start value](#), see on page 46

[End value](#), see on page 46

[Decimal point](#), see on page 46

[Scale units](#), see on page 47

[Sampling time \(s\)](#), see on page 48

[Average filter](#), see on page 48

[Offset](#), see on page 49

[Linearization](#), see on page 49

[Totalization](#), see on page 49

It is only available if the **Operational mode** parameter in the **General** menu (see on page 34) is set to any dual channel mode. Furthermore it is only available if the **Linearization** parameter in the **IN 2 properties** menu (see on page 49) is set to either "1 – 1 QUADRANT" or "2 – 4 QUADRANT".

[IN 2 Linearization menu](#), see the "6.7 IN 2 linearization menu" section on page 50

[P1\(X\)](#), see on page 50

...

[P24\(X\)](#), see on page 50

[P1\(Y\)](#), see on page 50

...

[P24\(Y\)](#), see on page 50

It is only available if the **Operational mode** parameter in the **General** menu (see on page 34) is set to any dual channel mode. Furthermore it is only available if the **Totalization** parameter in the **IN 2 properties** menu (see on page 49) is set to "YES".

**IN 2 totalization menu**, see the "6.8 IN 2 totalization menu" section on page 53

[Time base](#), see on page 53

[Divider](#), see on page 54

[Decimal point](#), see on page 54

[Scale units](#), see on page 54

It is only available if the **Operational mode** parameter in the **General** menu (see on page 34) is set to any dual channel mode.

**Linkage properties menu**, see the "6.9 Linkage properties menu" section on page 56

[Factor](#), see on page 56

[Divider](#), see on page 56

[Additive value](#), see on page 56

[Decimal point](#), see on page 57

[Scale units](#), see on page 57

It is only available for devices with order codes AVI, DO or RO.

**Preselection values menu**, see the "6.10 Preselection values menu" section on page 59

[Preselection 1](#), see on page 59

[Preselection 2](#), see on page 59

[Preselection 3](#), see on page 59

[Preselection 4](#), see on page 60

It is only available for devices with order codes AVI, DO or RO.

**Preselection 1 menu**, see the "6.11 Preselection 1 menu" section on page 61

**Source 1**, see on page 61

**Mode 1**, see on page 61

**Hysteresis 1**, see on page 63

**Pulse time 1 (s)**, see on page 63

**Output target 1**, see on page 63

**Output polarity 1**, see on page 63

**Output lock 1**, see on page 64

**Start up delay 1 (s)**, see on page 64

**Event color 1**, see on page 64

It is only available for devices with order codes AVI, DO or RO.

**Preselection 2 menu**, see the "6.12 Preselection 2 menu" section on page 65

**Source 2**, see on page 65

**Mode 2**, see on page 65

**Hysteresis 2**, see on page 65

**Pulse time 2 (s)**, see on page 65

**Output target 2**, see on page 65

**Output polarity 2**, see on page 65

**Output lock 2**, see on page 66

**Start up delay 2 (s)**, see on page 66

**Event color 2**, see on page 66

It is only available for devices with order codes AVI, DO or RO.

**Preselection 3 menu**, see the "6.13 Preselection 3 menu" section on page 67

**Source 3**, see on page 67

**Mode 3**, see on page 67

**Hysteresis 3**, see on page 67

**Pulse time 3 (s)**, see on page 67

**Output target 3**, see on page 67

**Output polarity 3**, see on page 67

**Output lock 3**, see on page 68

**Start up delay 3 (s)**, see on page 68

**Event color 3**, see on page 68

It is only available for devices with order codes AVI, D0 or R0.

**Preselection 4 menu**, see the "6.14 Preselection 4 menu" section on page 69

**Source 4**, see on page 69

**Mode 4**, see on page 69

**Hysteresis 4**, see on page 69

**Pulse time 4 (s)**, see on page 69

**Output target 4**, see on page 69

**Output polarity 4**, see on page 69

**Output lock 4**, see on page 70

**Start up delay 4 (s)**, see on page 70

**Event color 4**, see on page 70

It is only available for devices with order codes AVI and D0.

**Serial menu**, see the "6.15 Serial menu" section on page 71

**Unit number**, see on page 71

**Serial baud rate**, see on page 71

**Serial format**, see on page 71

**Serial init**, see on page 72

**Serial protocol**, see on page 72

**Serial timer (s)**, see on page 73

**Serial value**, see on page 73

It is only available for devices with order code AVI.

**Analog OUT menu**, see the "6.16 Analog OUT menu" section on page 74

**Analog source**, see on page 74

**Analog format**, see on page 75

**Analog start**, see on page 75

**Analog end**, see on page 75

**Analog gain (%)**, see on page 75

**Analog offset %**, see on page 76

<b>Command menu</b> , see the "6.17 Command menu" section on page 77
<b>Input 1 action</b> , see on page 77
<b>Input 1 config.</b> , see on page 79
<b>Input 2 action</b> , see on page 79
<b>Input 2 config.</b> , see on page 79
<b>Input 3 action</b> , see on page 79
<b>Input 3 config.</b> , see on page 79

<b>Display menu</b> , see the "6.18 Display menu" section on page 80
<b>Start display</b> , see on page 80
<b>Source single</b> , see on page 80
<b>Source dual top</b> , see on page 81
<b>Source dual down</b> , see on page 81
<b>Color</b> , see on page 82
<b>Brightness</b> , see on page 82
<b>Contrast</b> , see on page 82
<b>Screen saver</b> , see on page 83
<b>Up-date-time</b> , see on page 83
<b>Font</b> , see on page 83

## 6.2 General menu

The default values are highlighted with grey background.

### Operational mode

This parameter allows to set the desired measuring function.

0	SINGLE	Single channel mode, only input 1 is used
1	DUAL	Dual channel mode, input 1 and input 2 are used in a separate way
2	IN 1 + IN 2	Dual channel mode, input 1 is added to input 2 (sum)
3	IN 1 - IN 2	Dual channel mode, input 2 is subtracted from input 1 (difference)
4	IN 1 x IN 2	Dual channel mode, input 1 is multiplied by input 2 (multiplication)
5	IN 1 / IN 2	Dual channel mode, input 1 is divided by input 2 (division)

### Pin preselection

This parameter allows to set the PIN code to lock the quick start of the **Preselection values** menu used to enter the preselection values, see the "5.2 Screen structure during operation" section on page 27. Refer also to the "6.10 Preselection values menu" section on page 59. Master PIN is 6079.

This lock function is only useful if used along with the lock function set in the **Pin parameter**.

0000	No lock
...	
9999	Access after entering PIN Code 9999

### Pin parameter

This parameter sets the PIN code for the lock function of all parameters. The Master PIN is 6079.

0000	No lock
...	
9999	Parametrization of the unit after entering PIN code 9999

**Back up memory**

<b>0</b>	<b>NO</b>	No memory backup following a power failure
<b>1</b>	<b>YES</b>	Backup memory following a power failure, the current values will be saved

**Factory settings**

At any time you can return all settings to the factory default values.

Default values are highlighted with **grey background** in this manual.

**WARNING**

This action will reset all parameters to factory default values and customised settings will be lost. After reset you will have to repeat your individual set-up procedure.

<b>0</b>	<b>NO</b>	No default values are loaded
<b>1</b>	<b>YES</b>	Load default values of all parameters

### 6.3 IN 1 properties menu

The **IN 1 properties** menu is used to configure the characteristics of the input 1.

#### Configuration

This parameter sets the characteristics of the analogue input 1.

<b>0</b>	<b>-10...10V</b>	-10 ... +10 V
<b>1</b>	<b>0...20MA</b>	0 ... 20 mA
<b>2</b>	<b>4...20MA</b>	4 ... 20 mA

#### Start value

This parameter sets the display value for an analogue input 1 signal of 0 V or 0 mA or 4 mA. Signal values between **Start value** and **End value** behave proportionally.

<b>-99999</b>	Smallest start value
<b>+00000</b>	Default value
<b>+99999</b>	Highest start value

#### End value

This parameter sets the display value for an analogue input 1 signal of +10 V or 20 mA. Signal values between **Start value** and **End value** behave proportionally.

<b>-99999</b>	Smallest start value
<b>+10000</b>	Default value
<b>+99999</b>	Highest start value

#### Decimal point

It sets the position of the decimal point.

<b>0</b>	<b>NO</b>	No decimal point
<b>1</b>	<b>0000000.0</b>	Decimal point placed in the specified position
<b>2</b>	<b>000000.00</b>	Decimal point placed in the specified position
<b>3</b>	<b>00000.000</b>	Decimal point placed in the specified position
<b>4</b>	<b>0000.0000</b>	Decimal point placed in the specified position
<b>5</b>	<b>000.00000</b>	Decimal point placed in the specified position
<b>6</b>	<b>00.000000</b>	Decimal point placed in the specified position

7	0.0000000	Decimal point placed in the specified position
---	-----------	--

### Scale units

This parameter sets the required engineering unit. It does not affect the calculation of the display value. The number of decimal places must be set in the [Decimal point](#) parameter.

0	V
1	mV
2	A
3	mA
4	km/h
5	mph
6	feet/min
7	inch/min
8	g
9	kg
10	oz
11	W
12	kW
13	VA
14	mm
15	cm
16	m
17	inch
18	feet
19	C
20	F
21	K
22	1/sec
23	1/min
24	1/h
25	gal/min
26	Pa
27	kPa
28	%

		A customized measuring unit with up to 16 digits can be edited using this parameter.																																																																																																
29	Edit unit	<p>When you press the <b>ok</b> key the <b>Edit Unit</b> menu appears.</p> <p>A measuring unit can be created using the arrow keys (by pressing and holding the arrow key down the characters scroll fast).</p> <p>Press the <b>ok</b> key to save the <b>Edit Unit</b> menu.</p> <p>Press the <b>C</b> key to close the <b>Edit Unit</b> menu.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr><td></td><td>!</td><td>"</td><td>#</td><td>\$</td><td>%</td><td>&amp;</td><td>'</td><td>(</td><td>)</td><td>*</td><td>+</td><td>,</td><td>-</td><td>.</td><td>/</td></tr> <tr><td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>:</td><td>;</td><td>&lt;</td><td>=</td><td>&gt;</td><td>?</td></tr> <tr><td>@</td><td>A</td><td>B</td><td>C</td><td>D</td><td>E</td><td>F</td><td>G</td><td>H</td><td>I</td><td>J</td><td>K</td><td>L</td><td>M</td><td>N</td><td>O</td></tr> <tr><td>P</td><td>Q</td><td>R</td><td>S</td><td>T</td><td>U</td><td>V</td><td>W</td><td>X</td><td>Y</td><td>Z</td><td>[</td><td>\</td><td>]</td><td>^</td><td>-</td></tr> <tr><td>`</td><td>a</td><td>b</td><td>c</td><td>d</td><td>e</td><td>f</td><td>g</td><td>h</td><td>i</td><td>j</td><td>k</td><td>l</td><td>m</td><td>n</td><td>o</td></tr> <tr><td>p</td><td>q</td><td>r</td><td>s</td><td>t</td><td>u</td><td>v</td><td>w</td><td>x</td><td>y</td><td>z</td><td>{</td><td>}</td><td> </td><td>~</td><td></td></tr> </table>		!	"	#	\$	%	&	'	(	)	*	+	,	-	.	/	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z	[	\	]	^	-	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o	p	q	r	s	t	u	v	w	x	y	z	{	}		~	
	!	"	#	\$	%	&	'	(	)	*	+	,	-	.	/																																																																																			
0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?																																																																																			
@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O																																																																																			
P	Q	R	S	T	U	V	W	X	Y	Z	[	\	]	^	-																																																																																			
`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o																																																																																			
p	q	r	s	t	u	v	w	x	y	z	{	}		~																																																																																				

### Sampling time (s)

It allows to set the sampling interval. This time interval sets the time between the single samples of the analogue signals. It directly affects the response time of the unit. The value is expressed in seconds (s).

0.0010	Shortest Sampling time
00.010	Default value
60.000	Longest Sampling time

### Average filter

Selectable average filter function to avoid measuring fluctuations.

0	OFF	No average value will be created
1	2 cycle average	Floating average within 2 cycles
2	4 cycle average	Floating average within 4 cycles
3	8 cycle average	Floating average within 8 cycles
4	16 cycle average	Floating average within 16 cycles

**Offset**

This parameter allows to set the zero offset / tare of input 1.

This parameter does not affect the Totalization function, see the "6.5 IN 1 totalization menu" on page 43.

<b>-99999</b>	Smallest offset value
<b>+00000</b>	Default value
<b>+99999</b>	Highest offset value

**Linearization**

This parameter activates and sets the linearisation function. See the "6.4 IN 1 linearization menu" section on page 40 and the "6.4.1 Description of the linearisation function" section on page 40.

<b>0</b>	<b>OFF</b>	No linearisation
<b>1</b>	<b>1 QUADRANT</b>	Linearisation using 1 quadrant (see on page 40).
<b>2</b>	<b>4 QUADRANT</b>	Linearisation using 4 quadrants (see on page 40).

**Totalization**

This parameter activates the totalization function. The totalization function is directly affected by the set operational mode (see the **Operational mode** parameter on page 34). For complete information please refer to the "6.5 IN 1 totalization menu" section on page 43.

<b>0</b>	<b>NO</b>	No totalization
<b>1</b>	<b>YES</b>	Totalization is active (see on page 43).

## 6.4 IN 1 linearization menu

The linearisation function is configured in this menu. This menu is displayed only if the **Linearization** parameter in the **IN 1 properties** menu (see on page 39) is set to either "1 – 1 QUADRANT" or "2 – 4 QUADRANT"; if 0 – OFF option is set the **IN 1 linearization** menu does not appear.

For a complete description of the linearisation function and some examples refer to the "6.4.1 Description of the linearisation function" section below.

### P1(X)

...

### P24(X)

X-coordinate of the linearisation point.

This value represents the display value the unit shows on the display without linearisation.

-99999999	Smallest X-coordinate
+00000000	Default value
+99999999	Largest X-coordinate

### P1(Y)

...

### P24(Y)

Y-coordinate of the linearisation point.

This is the display value the unit will show on the display after linearisation.



#### EXAMPLE

**P2(X)** parameter value will be replaced by **P2(Y)** parameter value.

-99999999	Smallest Y-coordinate
+00000000	Default value
+99999999	Largest Y-coordinate

## 6.4.1 Description of the linearisation function

The linearisation function allows to convert a linear input signal into a non-linear representation (or vice versa). 24 programmable X / Y coordinates (interpolation points) are available, they can be freely arranged over the whole conversion range at any desired distance. The unit uses linear interpolation between two coordinates. Therefore it is advisable to set several coordinates


where the curvature is greater and only few coordinates where the curvature is lesser.

If you need to set an individual linearisation curve, the **Linearization** parameter in the **IN 1 properties** menu (see on page 39) must be set to either "1 - 1 QUADRANT" or "2 - 4 QUADRANT" (see the diagrams below).


The parameters **P1(X)** to **P24(X)** are used to specify the coordinates on the x-axis. These are the measuring values that the unit would normally generate according to the actual input signal.

Parameters **P1(Y)** to **P24(Y)** are the values that the unit will generate instead of the X values, i.e. for instance **P5(Y)** replaces **P5(X)** etc.

The X coordinates must use continuously increasing settings, i.e. **P1(X)** must have the lowest setting while **P24(X)** must have the highest setting (**P1(X) < P2(X) < P3(X) ... < P23(X) < P24(X)**). If the measured value is greater than the last defined X value, the corresponding Y value is displayed.



Example: Linearization Mode: 1 Quadrant  
\* Linearization is point symmetric to 1. Quadrant



Example: Linearization Mode: 4 Quadrant


If the **Linearization** parameter in the **IN 1 properties** menu is set to "1 - 1 QUADRANT", **P1(X)** parameter must be set to zero. Linearisation is only defined in the positive range and the negative range will be mirrored symmetrical with respect to the central point.

If the **Linearization** parameter in the **IN 1 properties** menu is set to "2 - 4 QUADRANT", **P1(X)** parameter can be set also to a negative value. If the measured value is smaller than **P1(X)**, **P1(Y)** is displayed.



### EXAMPLE

We want to display the filling quantity (volume) of a tank (see the Figure below) by using a pressure sensor mounted on the bottom of the tank. In this application, the analogue signal information about pressure is proportional to the filling level, but not to the filling quantity.



To solve the problem, we divide the non linear part of the tank into 14 sections. We set the expected display values of the pressure sensor in the **P1(X)** to **P15(X)** parameters.

For the linear part of the tank it is sufficient to set the final pressure value in the **P16(X)** parameter.

It is now possible to easily calculate the appropriate filling quantities ad enter the relevant values in the **P1(Y)** to **P16(Y)** parameters.

## 6.5 IN 1 totalization menu

The totalization function is configured in this menu. This menu is displayed only if the **Totalization** parameter in the **IN 1 properties** menu (see on page 39) is set to "YES"; if "NO" option is set the **IN 1 totalization** menu does not appear.



### NOTE

Please note that the totalization function is directly affected by the set operational mode (see the **Operational mode** parameter on page 34), according to the following table.

Operational mode	Totalization		
	INPUT 1 TOTAL	INPUT 2 TOTAL	LINKAGE TOTAL
SINGLE	active	→ 0	→ 0
DUAL	active	active	→ 0
IN 1 + IN 2	active	active	Total 1 + Total 2
IN 1 - IN 2	active	active	Total 1 - Total 2
IN 1 x IN 2	active	active	→ 0
IN 1 / IN 2	active	active	→ 0

### Time base

This parameter sets the time base of the totalization value. In other words it sets the time interval between two data recordings.

0	SECONDS	The current value is added to INPUT 1 TOTAL every second
1	MINUTES	The current value is added to INPUT 1 TOTAL every minute
2	HOURS	The current value is added to INPUT 1 TOTAL every hour
3	COMMAND	The current value is added to INPUT 1 TOTAL when we use the "25 - ADD TO TOTAL 1" command in order to operate the control input. For further information please refer to the <b>Input 1 action</b> parameter in the "6.17 Command menu" section on page 77.

### Divider

This parameter allows to set the divisional factor of the totalization value.

0	1	No division
1	10	The result of the totalization is divided by 10

2	100	The result of the totalization is divided by 100
3	1000	The result of the totalization is divided by 1000

### Decimal point

It sets the position of the decimal point.

0	NO	No decimal point
1	0000000.0	Decimal point placed in the specified position
2	000000.00	Decimal point placed in the specified position
3	00000.000	Decimal point placed in the specified position
4	0000.0000	Decimal point placed in the specified position
5	000.00000	Decimal point placed in the specified position
6	00.000000	Decimal point placed in the specified position
7	0.0000000	Decimal point placed in the specified position

### Scale units

This parameter sets the required engineering unit. It does not affect the calculation of the display value. The number of decimal places must be set in the **Decimal point** parameter.

0	V	
1	mV	
2	A	
3	mA	
4	km/h	
5	mph	
6	feet/min	
7	inch/min	
8	g	
9	kg	
10	oz	
11	W	
12	kW	
13	VA	
14	mm	
15	cm	

16	m																																																																																											
17	inch																																																																																											
18	feet																																																																																											
19	C																																																																																											
20	F																																																																																											
21	K																																																																																											
22	1/sec																																																																																											
23	1/min																																																																																											
24	1/h																																																																																											
25	gal/min																																																																																											
26	Pa																																																																																											
27	kPa																																																																																											
28	%																																																																																											
29	Edit unit	<p>A customized measuring unit with up to 16 digits can be edited using this parameter.</p> <p>When you press the <b>ok</b> key the <b>Edit Unit</b> menu appears.</p> <p>A measuring unit can be created using the arrow keys (by pressing and holding the arrow key down the characters scroll fast).</p> <p>Press the <b>ok</b> key to save the <b>Edit Unit</b> menu.</p> <p>Press the <b>C</b> key to close the <b>Edit Unit</b> menu.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>!</td><td>"</td><td>#</td><td>\$</td><td>%</td><td>&amp;</td><td>'</td><td>(</td><td>)</td><td>*</td><td>+</td><td>,</td><td>-</td><td>.</td><td>/</td></tr> <tr> <td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>:</td><td>;</td><td>&lt;</td><td>=</td><td>&gt;</td></tr> <tr> <td>@</td><td>A</td><td>B</td><td>C</td><td>D</td><td>E</td><td>F</td><td>G</td><td>H</td><td>I</td><td>J</td><td>K</td><td>L</td><td>M</td><td>N</td></tr> <tr> <td>P</td><td>Q</td><td>R</td><td>S</td><td>T</td><td>U</td><td>V</td><td>W</td><td>X</td><td>Y</td><td>Z</td><td>[</td><td>\</td><td>]</td><td>^</td></tr> <tr> <td>`</td><td>a</td><td>b</td><td>c</td><td>d</td><td>e</td><td>f</td><td>g</td><td>h</td><td>i</td><td>j</td><td>k</td><td>l</td><td>m</td><td>n</td></tr> <tr> <td>p</td><td>q</td><td>r</td><td>s</td><td>t</td><td>u</td><td>v</td><td>w</td><td>x</td><td>y</td><td>z</td><td>{</td><td>}</td><td>~</td><td></td></tr> </table>	!	"	#	\$	%	&	'	(	)	*	+	,	-	.	/	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	P	Q	R	S	T	U	V	W	X	Y	Z	[	\	]	^	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	p	q	r	s	t	u	v	w	x	y	z	{	}	~	
!	"	#	\$	%	&	'	(	)	*	+	,	-	.	/																																																																														
0	1	2	3	4	5	6	7	8	9	:	;	<	=	>																																																																														
@	A	B	C	D	E	F	G	H	I	J	K	L	M	N																																																																														
P	Q	R	S	T	U	V	W	X	Y	Z	[	\	]	^																																																																														
`	a	b	c	d	e	f	g	h	i	j	k	l	m	n																																																																														
p	q	r	s	t	u	v	w	x	y	z	{	}	~																																																																															

## 6.6 IN 2 properties menu

The **IN 2 properties** menu is used to configure the characteristics of the input 2. This menu is displayed only if the **Operational mode** parameter is set to any dual channel mode (DUAL, IN 1 + IN 2, IN 1 - IN 2, IN 1 x IN 2, IN 1 / IN 2). If the SINGLE single channel mode is selected, this menu is hidden. Refer to the "6.2 General menu" section on page 34.

### Configuration

This parameter sets the characteristics of the analogue input 2.

0	-10...10V	-10 ... +10 V
1	0...20MA	0 ... 20 mA
2	4...20MA	4 ... 20 mA

### Start value

This parameter sets the display value for an analogue input 2 signal of 0 V or 0 mA or 4 mA. Signal values between **Start value** and **End value** behave proportionally.

-99999	Smallest start value
+00000	Default value
+99999	Highest start value

### End value

This parameter sets the display value for an analogue input 2 signal of +10 V or 20 mA. Signal values between **Start value** and **End value** behave proportionally.

-99999	Smallest start value
+10000	Default value
+99999	Highest start value

### Decimal point

It sets the position of the decimal point.

0	NO	No decimal point
1	0000000.0	Decimal point placed in the specified position
2	000000.00	Decimal point placed in the specified position
3	00000.000	Decimal point placed in the specified position

4	0000.0000	Decimal point placed in the specified position
5	000.00000	Decimal point placed in the specified position
6	00.000000	Decimal point placed in the specified position
7	0.0000000	Decimal point placed in the specified position

### Scale units

This parameter sets the required engineering unit. It does not affect the calculation of the display value. The number of decimal places must be set in the **Decimal point** parameter.

0	V
1	mV
2	A
3	mA
4	km/h
5	mph
6	feet/min
7	inch/min
8	g
9	kg
10	oz
11	W
12	kW
13	VA
14	mm
15	cm
16	m
17	inch
18	feet
19	C
20	F
21	K
22	1/sec
23	1/min
24	1/h
25	gal/min

<b>26</b>	<b>Pa</b>																																																																																																	
<b>27</b>	<b>kPa</b>																																																																																																	
<b>28</b>	<b>%</b>																																																																																																	
<b>29</b>	<b>Edit unit</b>	<p>A customized measuring unit with up to 16 digits can be edited using this parameter.</p> <p>When you press the <b>ok</b> key the <b>Edit Unit</b> menu appears.</p> <p>A measuring unit can be created using the arrow keys (by pressing and holding the arrow key down the characters scroll fast).</p> <p>Press the <b>ok</b> key to save the <b>Edit Unit</b> menu.</p> <p>Press the <b>C</b> key to close the <b>Edit Unit</b> menu.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr><td></td><td>!</td><td>"</td><td>#</td><td>\$</td><td>%</td><td>&amp;</td><td>'</td><td>(</td><td>)</td><td>*</td><td>+</td><td>,</td><td>-</td><td>.</td><td>/</td></tr> <tr><td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>:</td><td>;</td><td>&lt;</td><td>=</td><td>&gt;</td><td>?</td></tr> <tr><td>@</td><td>A</td><td>B</td><td>C</td><td>D</td><td>E</td><td>F</td><td>G</td><td>H</td><td>I</td><td>J</td><td>K</td><td>L</td><td>M</td><td>N</td><td>O</td></tr> <tr><td>P</td><td>Q</td><td>R</td><td>S</td><td>T</td><td>U</td><td>V</td><td>W</td><td>X</td><td>Y</td><td>Z</td><td>[</td><td>\</td><td>]</td><td>^</td><td>_</td></tr> <tr><td>'</td><td>a</td><td>b</td><td>c</td><td>d</td><td>e</td><td>f</td><td>g</td><td>h</td><td>i</td><td>j</td><td>k</td><td>l</td><td>m</td><td>n</td><td>o</td></tr> <tr><td>p</td><td>q</td><td>r</td><td>s</td><td>t</td><td>u</td><td>v</td><td>w</td><td>x</td><td>y</td><td>z</td><td>{</td><td>}</td><td> </td><td>~</td><td></td></tr> </table>		!	"	#	\$	%	&	'	(	)	*	+	,	-	.	/	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z	[	\	]	^	_	'	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o	p	q	r	s	t	u	v	w	x	y	z	{	}		~	
	!	"	#	\$	%	&	'	(	)	*	+	,	-	.	/																																																																																			
0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?																																																																																			
@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O																																																																																			
P	Q	R	S	T	U	V	W	X	Y	Z	[	\	]	^	_																																																																																			
'	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o																																																																																			
p	q	r	s	t	u	v	w	x	y	z	{	}		~																																																																																				

**Sampling time (s)**

It allows to set the sampling interval. This time interval sets the time between the single samples of the analogue signals. It directly affects the response time of the unit. The value is expressed in seconds (s).

<b>0.0010</b>	Shortest Sampling time
<b>00.010</b>	Default value
<b>60.000</b>	Longest Sampling time

**Average filter**

Selectable average filter function to avoid measuring fluctuations

<b>0</b>	<b>OFF</b>	No average value will be created
<b>1</b>	<b>2 cycle average</b>	Floating average within 2 cycles
<b>2</b>	<b>4 cycle average</b>	Floating average within 4 cycles
<b>3</b>	<b>8 cycle average</b>	Floating average within 8 cycles
<b>4</b>	<b>16 cycle average</b>	Floating average within 16 cycles

**Offset**

This parameter allows to set the zero offset / tare of input 2.

This parameter does not affect the Totalization function, see the "6.8 IN 2 totalization menu" on page 53.

<b>-99.999</b>	Smallest offset value
<b>00000</b>	Default value
<b>+99.999</b>	Highest offset value

**Linearization**

This parameter activates and sets the linearisation function. See the "6.7 IN 2 linearization menu" section on page 50 and the "6.7.1 Description of the linearisation function" section on page 50.

<b>0</b>	<b>OFF</b>	No linearisation
<b>1</b>	<b>1 QUADRANT</b>	Linearisation using 1 quadrant (see on page 50).
<b>2</b>	<b>4 QUADRANT</b>	Linearisation using 4 quadrants (see on page 50).

**Totalization**

This parameter activates the totalization function. The totalization function is directly affected by the set operational mode (see the **Operational mode** parameter on page 34). For complete information please refer to the "6.8 IN 2 totalization menu" section on page 53.

<b>0</b>	<b>NO</b>	No totalization
<b>1</b>	<b>YES</b>	Totalization is active (see on page 53).

## 6.7 IN 2 linearization menu

The linearisation function is configured in this menu. This menu is displayed only if the **Operational mode** parameter is set to any dual channel mode (DUAL, IN 1 + IN 2, IN 1 - IN 2, IN 1 x IN 2, IN 1 / IN 2). If the SINGLE single channel mode is selected, this menu is hidden. Refer to the "6.2 General menu" section on page 34. Furthermore it is displayed only if the **Linearization** parameter in the **IN 2 properties** menu (see on page 49) is set to either "1 - 1 QUADRANT" or "2 - 4 QUADRANT"; if 0 - OFF option is set the **IN 2 linearization** menu does not appear.

For a complete description of the linearisation function and some examples refer to the "6.7.1 Description of the linearisation function" section below.

### P1(X)

...

### P24(X)

X-coordinate of the linearisation point.

This value represents the display value the unit shows on the display without linearisation.

-99999999	Smallest X-coordinate
+00000000	Default value
+99999999	Largest X-coordinate

### P1(Y)

...

### P24(Y)

Y-coordinate of the linearisation point.

This is the display value the unit will show on the display after linearisation.



### EXAMPLE

**P2(X)** parameter value will be replaced by **P2(Y)** parameter value.

-99999999	Smallest Y-coordinate
+00000000	Default value
+99999999	Largest Y-coordinate

## 6.7.1 Description of the linearisation function

The linearisation function allows to convert a linear input signal into a non-linear representation (or vice versa). 24 programmable X / Y coordinates


(interpolation points) are available, they can be freely arranged over the whole conversion range at any desired distance. The unit uses linear interpolation between two coordinates. Therefore it is advisable to set several coordinates where the curvature is greater and only few coordinates where the curvature is lesser.

If you need to set an individual linearisation curve, the **Linearization** parameter in the **IN 2 properties** menu (see on page 49) must be set to either "1 - 1 QUADRANT" or "2 - 4 QUADRANT" (see the diagrams below).


The parameters **P1(X)** to **P24(X)** are used to specify the coordinates on the x-axis. These are the measuring values that the unit would normally generate according to the actual input signal.

Parameters **P1(Y)** to **P24(Y)** are the values that the unit will generate instead of the X values, i.e. for instance **P5(Y)** replaces **P5(X)** etc.

The X coordinates must use continuously increasing settings, i.e. **P1(X)** must have the lowest setting while **P24(X)** must have the highest setting ( $P1(X) < P2(X) < P3(X) \dots < P23(X) < P24(X)$ ). If the measured value is greater than the last defined X value, the corresponding Y value is displayed.



Example: Linearization Mode: 1 Quadrant  
\* Linearization is point symmetric to 1. Quadrant



Example: Linearization Mode: 4 Quadrant


If the **Linearization** parameter in the **IN 2 properties** menu is set to "1 - 1 QUADRANT", **P1(X)** parameter must be set to zero. Linearisation is only defined in the positive range and the negative range will be mirrored symmetrical with respect to the central point.

If the **Linearization** parameter in the **IN 2 properties** menu is set to "2 - 4 QUADRANT", **P1(X)** parameter can be set also to a negative value. If the measured value is smaller than **P1(X)**, **P1(Y)** is displayed.



### EXAMPLE

We want to display the filling quantity (volume) of a tank (see the Figure below) by using a pressure sensor mounted on the bottom of the tank. In this application, the analogue signal information about pressure is proportional to the filling level, but not to the filling quantity.



To solve the problem, we divide the non linear part of the tank into 14 sections. We set the expected display values of the pressure sensor in the **P1(X)** to **P15(X)** parameters.

For the linear part of the tank it is sufficient to set the final pressure value in the **P16(X)** parameter.

It is now possible to easily calculate the appropriate filling quantities ad enter the relevant values in the **P1(Y)** to **P16(Y)** parameters.

## 6.8 IN 2 totalization menu

The totalization function is configured in this menu. This menu is displayed only if the **Operational mode** parameter is set to any dual channel mode (DUAL, IN 1 + IN 2, IN 1 - IN 2, IN 1 x IN 2, IN 1 / IN 2). If the SINGLE single channel mode is selected, this menu is hidden. Refer to the "6.2 General menu" section on page 34. Furthermore it is displayed only if the **Totalization** parameter in the **IN 2 properties** menu (see on page 49) is set to "YES"; if "NO" option is set the **IN 2 totalization** menu does not appear.



### NOTE

Please note that the totalization function is directly affected by the set operational mode (see the **Operational mode** parameter on page 34), according to the following table.

<b>Operational mode</b>	<b>Totalization</b>		
	<b>INPUT 1 TOTAL</b>	<b>INPUT 2 TOTAL</b>	<b>LINKAGE TOTAL</b>
<b>SINGLE</b>	active	➔ 0	➔ 0
<b>DUAL</b>	active	active	➔ 0
<b>IN 1 + IN 2</b>	active	active	Total 1 + Total 2
<b>IN 1 - IN 2</b>	active	active	Total 1 - Total 2
<b>IN 1 x IN 2</b>	active	active	➔ 0
<b>IN 1 / IN 2</b>	active	active	➔ 0

### Time base

This parameter sets the time base of the totalization value. In other words it sets the time interval between two data recordings.

<b>0</b>	<b>SECONDS</b>	The current value is added to INPUT 2 TOTAL every second
<b>1</b>	<b>MINUTES</b>	The current value is added to INPUT 2 TOTAL every minute
<b>2</b>	<b>HOURS</b>	The current value is added to INPUT 2 TOTAL every hour
<b>3</b>	<b>COMMAND</b>	The current value is added to INPUT 2 TOTAL when we use the "26 - ADD TO TOTAL 2" command in order to operate the control input. For further information please refer to the <b>Input 2 action</b> parameter in the "6.17 Command menu" section on page 77.

**Divider**

This parameter allows to set the divisional factor of the totalization value.

<b>0</b>	<b>1</b>	No division
<b>1</b>	<b>10</b>	The result of the totalization is divided by 10
<b>2</b>	<b>100</b>	The result of the totalization is divided by 100
<b>3</b>	<b>1000</b>	The result of the totalization is divided by 1000

**Decimal point**

It sets the position of the decimal point.

<b>0</b>	<b>NO</b>	No decimal point
<b>1</b>	<b>0000000.0</b>	Decimal point placed in the specified position
<b>2</b>	<b>000000.00</b>	Decimal point placed in the specified position
<b>3</b>	<b>00000.000</b>	Decimal point placed in the specified position
<b>4</b>	<b>0000.0000</b>	Decimal point placed in the specified position
<b>5</b>	<b>000.00000</b>	Decimal point placed in the specified position
<b>6</b>	<b>00.000000</b>	Decimal point placed in the specified position
<b>7</b>	<b>0.0000000</b>	Decimal point placed in the specified position

**Scale units**

This parameter sets the required engineering unit. It does not affect the calculation of the display value. The number of decimal places must be set in the **Decimal point** parameter.

<b>0</b>	<b>V</b>	
<b>1</b>	<b>mV</b>	
<b>2</b>	<b>A</b>	
<b>3</b>	<b>mA</b>	
<b>4</b>	<b>km/h</b>	
<b>5</b>	<b>mph</b>	
<b>6</b>	<b>feet/min</b>	
<b>7</b>	<b>inch/min</b>	
<b>8</b>	<b>g</b>	
<b>9</b>	<b>kg</b>	
<b>10</b>	<b>oz</b>	
<b>11</b>	<b>W</b>	

12	kW																																																																																											
13	VA																																																																																											
14	mm																																																																																											
15	cm																																																																																											
16	m																																																																																											
17	inch																																																																																											
18	feet																																																																																											
19	C																																																																																											
20	F																																																																																											
21	K																																																																																											
22	1/sec																																																																																											
23	1/min																																																																																											
24	1/h																																																																																											
25	gal/min																																																																																											
26	Pa																																																																																											
27	kPa																																																																																											
28	%																																																																																											
29	Edit unit	<p>A customized measuring unit with up to 16 digits can be edited using this parameter.</p> <p>When you press the <b>ok</b> key the <b>Edit Unit</b> menu appears.</p> <p>A measuring unit can be created using the arrow keys (by pressing and holding the arrow key down the characters scroll fast).</p> <p>Press the <b>ok</b> key to save the <b>Edit Unit</b> menu.</p> <p>Press the <b>C</b> key to close the <b>Edit Unit</b> menu.</p> <table border="1" style="margin-top: 10px; width: 100%; text-align: center;"> <tr><td>!</td><td>"</td><td>#</td><td>\$</td><td>%</td><td>&amp;</td><td>'</td><td>(</td><td>)</td><td>*</td><td>+</td><td>,</td><td>-</td><td>.</td><td>/</td></tr> <tr><td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>:</td><td>;</td><td>&lt;</td><td>=</td><td>&gt;</td></tr> <tr><td>@</td><td>A</td><td>B</td><td>C</td><td>D</td><td>E</td><td>F</td><td>G</td><td>H</td><td>I</td><td>J</td><td>K</td><td>L</td><td>M</td><td>N</td></tr> <tr><td>P</td><td>Q</td><td>R</td><td>S</td><td>T</td><td>U</td><td>V</td><td>W</td><td>X</td><td>Y</td><td>Z</td><td>[</td><td>\</td><td>]</td><td>^</td></tr> <tr><td>`</td><td>a</td><td>b</td><td>c</td><td>d</td><td>e</td><td>f</td><td>g</td><td>h</td><td>i</td><td>j</td><td>k</td><td>l</td><td>m</td><td>n</td></tr> <tr><td>p</td><td>q</td><td>r</td><td>s</td><td>t</td><td>u</td><td>v</td><td>w</td><td>x</td><td>y</td><td>z</td><td>{</td><td>}</td><td>~</td><td></td></tr> </table>	!	"	#	\$	%	&	'	(	)	*	+	,	-	.	/	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	P	Q	R	S	T	U	V	W	X	Y	Z	[	\	]	^	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	p	q	r	s	t	u	v	w	x	y	z	{	}	~	
!	"	#	\$	%	&	'	(	)	*	+	,	-	.	/																																																																														
0	1	2	3	4	5	6	7	8	9	:	;	<	=	>																																																																														
@	A	B	C	D	E	F	G	H	I	J	K	L	M	N																																																																														
P	Q	R	S	T	U	V	W	X	Y	Z	[	\	]	^																																																																														
`	a	b	c	d	e	f	g	h	i	j	k	l	m	n																																																																														
p	q	r	s	t	u	v	w	x	y	z	{	}	~																																																																															

## 6.9 Linkage properties menu

In this menu the parameters that configure a combined operation work mode can be set. A "combined operation work mode" is any dual channel mode that involves an operation (addition, subtraction, multiplication, division). It is available only if the **Operational mode** parameter in the **General** menu is set to "2 = IN 1 + IN 2", "3 = IN 1 - IN 2", "4 IN 1 x IN 2" or "5 = IN 1 / IN 2" (see on page 34).



### NOTE

Parameters in the **IN 1 properties** and **IN 2 properties** menus must be set before activating the combined operation work mode.

The result of the combined operations can be scaled using the following parameters.

#### Factor

This parameter sets the factor by which the result of the combined operation will be multiplied.

<b>-99999999</b>	Smallest value
<b>+00000001</b>	Default value
<b>+99999999</b>	Highest value

#### Divider

This parameter sets the divider by which the result of the combined operation will be divided.

<b>-99999999</b>	Smallest value
<b>+00000001</b>	Default value
<b>+99999999</b>	Highest value

#### Additive value

This parameter sets the additive constant that will be added to the result of the combined operation.

<b>-99999999</b>	Smallest value
<b>+00000000</b>	Default value
<b>+99999999</b>	Highest value

**Decimal point**

It sets the position of the decimal point.

<b>0</b>	<b>NO</b>	No decimal point
<b>1</b>	<b>0000000.0</b>	Decimal point placed in the specified position
<b>2</b>	<b>000000.00</b>	Decimal point placed in the specified position
<b>3</b>	<b>00000.000</b>	Decimal point placed in the specified position
<b>4</b>	<b>0000.0000</b>	Decimal point placed in the specified position
<b>5</b>	<b>000.00000</b>	Decimal point placed in the specified position
<b>6</b>	<b>00.000000</b>	Decimal point placed in the specified position
<b>7</b>	<b>0.0000000</b>	Decimal point placed in the specified position

**Scale units**

This parameter sets the required engineering unit. It does not affect the calculation of the display value. The number of decimal places must be set in the **Decimal point** parameter.

<b>0</b>	<b>V</b>	
<b>1</b>	<b>mV</b>	
<b>2</b>	<b>A</b>	
<b>3</b>	<b>mA</b>	
<b>4</b>	<b>km/h</b>	
<b>5</b>	<b>mph</b>	
<b>6</b>	<b>feet/min</b>	
<b>7</b>	<b>inch/min</b>	
<b>8</b>	<b>g</b>	
<b>9</b>	<b>kg</b>	
<b>10</b>	<b>oz</b>	
<b>11</b>	<b>W</b>	
<b>12</b>	<b>kW</b>	
<b>13</b>	<b>VA</b>	
<b>14</b>	<b>mm</b>	
<b>15</b>	<b>cm</b>	
<b>16</b>	<b>m</b>	
<b>17</b>	<b>inch</b>	
<b>18</b>	<b>feet</b>	
<b>19</b>	<b>C</b>	

20	F																																																																																																	
21	K																																																																																																	
22	1/sec																																																																																																	
23	1/min																																																																																																	
24	1/h																																																																																																	
25	gal/min																																																																																																	
26	Pa																																																																																																	
27	kPa																																																																																																	
28	%																																																																																																	
29	Edit unit	<p>A customized measuring unit with up to 16 digits can be edited using this parameter.</p> <p>When you press the <b>ok</b> key the <b>Edit Unit</b> menu appears.</p> <p>A measuring unit can be created using the arrow keys (by pressing and holding the arrow key down the characters scroll fast).</p> <p>Press the <b>ok</b> key to save the <b>Edit Unit</b> menu.</p> <p>Press the <b>C</b> key to close the <b>Edit Unit</b> menu.</p> <table border="1" style="margin-top: 10px; width: 100%; text-align: center;"> <tr> <td></td><td>!</td><td>"</td><td>#</td><td>\$</td><td>%</td><td>&amp;</td><td>'</td><td>(</td><td>)</td><td>*</td><td>+</td><td>,</td><td>-</td><td>.</td><td>/</td></tr> <tr> <td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>:</td><td>;</td><td>&lt;</td><td>=</td><td>&gt;</td><td>?</td></tr> <tr> <td>@</td><td>A</td><td>B</td><td>C</td><td>D</td><td>E</td><td>F</td><td>G</td><td>H</td><td>I</td><td>J</td><td>K</td><td>L</td><td>M</td><td>N</td><td>O</td></tr> <tr> <td>P</td><td>Q</td><td>R</td><td>S</td><td>T</td><td>U</td><td>V</td><td>W</td><td>X</td><td>Y</td><td>Z</td><td>[</td><td>\</td><td>]</td><td>^</td><td>-</td></tr> <tr> <td>`</td><td>a</td><td>b</td><td>c</td><td>d</td><td>e</td><td>f</td><td>g</td><td>h</td><td>i</td><td>j</td><td>k</td><td>l</td><td>m</td><td>n</td><td>o</td></tr> <tr> <td>p</td><td>q</td><td>r</td><td>s</td><td>t</td><td>u</td><td>v</td><td>w</td><td>x</td><td>y</td><td>z</td><td>{</td><td>}</td><td> </td><td>~</td><td></td></tr> </table>		!	"	#	\$	%	&	'	(	)	*	+	,	-	.	/	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z	[	\	]	^	-	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o	p	q	r	s	t	u	v	w	x	y	z	{	}		~	
	!	"	#	\$	%	&	'	(	)	*	+	,	-	.	/																																																																																			
0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?																																																																																			
@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O																																																																																			
P	Q	R	S	T	U	V	W	X	Y	Z	[	\	]	^	-																																																																																			
`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o																																																																																			
p	q	r	s	t	u	v	w	x	y	z	{	}		~																																																																																				

## 6.10 Preselection values menu

The **Preselection values** menu is used to set the preselection values or the switching points.

The preselection values / switching points are always referred to the display value.

This menu is only available for devices with order codes AVI, DO or RO.

### Preselection 1

Preselection / switching point 1. The features of **Preselection 1** must be set in the **Preselection 1** menu, see the "6.11 Preselection 1 menu" section on page 61.

-99999999	Smallest value
+00001000	Default value
+99999999	Highest value

### Preselection 2

Preselection / switching point 2. The features of **Preselection 2** must be set in the **Preselection 2** menu, see the "6.12 Preselection 2 menu" section on page 65.

-99999999	Smallest value
+00002000	Default value
+99999999	Highest value

### Preselection 3

Preselection / switching point 3. The features of **Preselection 3** must be set in the **Preselection 3** menu, see the "6.13 Preselection 3 menu" section on page 67.

-99999999	Smallest value
+00003000	Default value
+99999999	Highest value

**Preselection 4**

Preselection / switching point 4. The features of **Preselection 1** must be set in the **Preselection 4** menu, see the "6.14 Preselection 4 menu" section on page 69.

<b>-99999999</b>	Smallest value
<b>+00004000</b>	Default value
<b>+99999999</b>	Highest value

### 6.11 Preselection 1 menu

The **Preselection 1** menu sets the characteristics of **Preselection 1**. It is only available for devices with order codes AVI, DO and RO.

#### Source 1

This parameter sets the reference source for **Preselection 1**.

<b>0</b>	<b>INPUT 1</b>	The reference source is input 1.
<b>1</b>	<b>INPUT 2</b>	The reference source is input 2.
<b>2</b>	<b>LINKAGE 1_2</b>	The reference source is the result of the combined operation of input 1 and input 2.
<b>3</b>	<b>INPUT 1 TOTAL</b>	The reference source is input 1 with totalization.
<b>4</b>	<b>INPUT 2 TOTAL</b>	The reference source is input 2 with totalization.
<b>5</b>	<b>LINKAGE TOTAL</b>	The reference source is the result of the combined operation of input 1 and input 2 with totalization.
<b>6</b>	<b>N.A.</b>	Reserved
<b>7</b>	<b>N.A.</b>	Reserved
<b>8</b>	<b>MINIMUM VALUE 1</b>	Minimum value, the reference source is input 1.
<b>9</b>	<b>MAXIMUM VALUE 1</b>	Maximum value, the reference source is input 1.
<b>10</b>	<b>MINIMUM VALUE 2</b>	Minimum value, the reference source is input 2.
<b>11</b>	<b>MAXIMUM VALUE 2</b>	Maximum value, the reference source is input 2.

The totalization depends on the selected operational mode, see the table in the "6.5 IN 1 totalization menu" section on page 43. See also the **Operational mode** parameter on page 34.

#### Mode 1

Switching conditions for **Preselection 1**. The output / relay / display switches under the following conditions:

<b>0</b>	<b> RESULT &gt;= PRES </b>	The absolute display value is greater than or equal to the absolute value of <b>Preselection 1</b> . If <b>Hysteresis 1</b> is greater than 0, the following switching condition is applied: Display value $\geq$ <b>Preselection 1</b> → ON Display value $<$ <b>Preselection 1 - Hysteresis 1</b> → OFF
<b>1</b>	<b> RESULT &lt;= PRES </b>	The absolute display value is less than or equal to

		<p>the absolute value of <b>Preselection 1</b> (start up delay setting – see the <b>Start up delay 1 (s)</b> parameter on page 64- is advisable).</p> <p>If <b>Hysteresis 1</b> is greater than 0, the following switching condition is applied:</p> <p>Display value <math>\leq</math> <b>Preselection 1</b> → ON</p> <p>Display value <math>&gt;</math> <b>Preselection 1 + Hysteresis 1</b> → OFF</p>
2	<b> RESULT  =  PRES </b>	<p>The absolute display value is equal to the absolute value of <b>Preselection 1</b>.</p> <p>A range (<b>Preselection 1 +/- 1/2 Hysteresis 1</b>) can be defined and monitored along with a hysteresis value.</p> <p>If <b>Hysteresis 1</b> is greater than 0, the following switching condition is applied:</p> <p>Display value <math>&gt;</math> <b>Preselection 1 + 1/2 Hysteresis 1</b> → OFF</p> <p>Display value <math>&lt;</math> <b>Preselection 1 - 1/2 Hysteresis 1</b> → OFF</p>
3	<b>RESULT &gt;= PRES</b>	<p>Display value is greater than or equal to <b>Preselection 1</b>, e.g. an overspeed id detected.</p> <p>If <b>Hysteresis 1</b> is greater than 0, the following switching condition is applied:</p> <p>Display value <math>\geq</math> <b>Preselection 1</b> → ON</p> <p>Display value <math>&lt;</math> <b>Preselection 1 - Hysteresis 1</b> → OFF</p>
4	<b>RESULT &lt;= PRES</b>	<p>Display value is less than or equal to <b>Preselection 1</b>, e.g. an underspeed is detected (start up delay setting –see the <b>Start up delay 1 (s)</b> parameter on page 64- is advisable).</p> <p>If <b>Hysteresis 1</b> is greater than 0, the following switching condition is applied:</p> <p>Display value <math>\leq</math> <b>Preselection 1</b> → ON</p> <p>Display value <math>&gt;</math> <b>Preselection 1 + Hysteresis 1</b> → OFF</p>
5	<b>RESULT = PRES</b>	<p>Display value is equal to <b>Preselection 1</b>. A range (<b>Preselection 1 +/- 1/2 Hysteresis 1</b>) can be defined and monitored along with a hysteresis value.</p> <p>If <b>Hysteresis 1</b> is greater than 0, the following switching condition is applied:</p> <p>Display value <math>&gt;</math> <b>Preselection 1 + 1/2 Hysteresis 1</b> → OFF</p> <p>Display value <math>&lt;</math> <b>Preselection 1 - 1/2 Hysteresis 1</b> → OFF</p>
6	<b>RES&gt;=PRES-TRAIL</b>	<p>Trailing <b>Preselection 1</b>:</p> <p>Display value is greater than or equal to</p>

		<b>Preselection 2 – Preselection 1</b> <b>Preselection 1</b> is the trailing preselection from <b>Preselection 2</b> .
--	--	---

**Hysteresis 1**

This parameter sets the switching hysteresis of the switch-off point for **Preselection 1** value.

00000	No switching hysteresis
...	
99999	Switching hysteresis = 99999

**Pulse time 1 (s)**

Duration of the output pulse for the switching condition of **Preselection 1** value.

00.000	No output pulse (static signal)
...	
60.000	Pulse duration = 60 seconds

**Output target 1**

Assignment of an output or relay for the switching condition of **Preselection 1** value.

If more than one switching condition is assigned to the output / relay, the output is set when one switching condition at least is true.

0	NO	No switching condition assigned
1	CTRL OUT 1	Switching condition assigned to "20 - Ctrl. Out 1"
2	CTRL OUT 2	Switching condition assigned to "21 - Ctrl. Out 2"
3	CTRL OUT 3	Switching condition assigned to "22 - Ctrl. Out 3"
4	CTRL OUT 4	Switching condition assigned to "23 - Ctrl. Out 4"
5	RELAY 1	Switching condition assigned to "27-28-29 - Rel. 1"
6	RELAY 2	Switching condition assigned to "30-31-32 - Rel. 2"

**Output polarity 1**

Polarity for the switching condition of **Preselection 1**.

0	ACTIVE HIGH	Switching condition is true → Active "HIGH"
1	ACTIVE LOW	Switching condition is true → Active "LOW"

**Output lock 1**

Latch for the switching condition of **Preselection 1**.

<b>0</b>	<b>NO</b>	No latch for <b>Preselection 1</b>
<b>1</b>	<b>YES</b>	Latch for <b>Preselection 1</b> (command <b>4 - LOCK RELEASE</b> -see the <b>Input 1 action</b> parameter on page 77- will clear the latch).

**Start up delay 1 (s)**

Start up delay setting for the switching condition of **Preselection 1**.

This adjustment only applies to the switching conditions **1 - |RESULT|<=|PRES|** and **4 - RESULT<=PRES** (see the **Mode 1** parameter on page 61).

<b>00.000</b>	No start up delay setting
...	
<b>60.000</b>	Start up delay setting expressed in seconds

**NOTE**

**Start up delay 3 (s)** and **Start up delay 4 (s)** (see on pages 68 and 70 respectively) have an automatic start up delay setting.

**Event color 1**

Event-depending change of colour of the display for the switching condition of **Preselection 1**. **Event color 1** has the lowest priority. **Event color 2**, **Event color 3** and **Event color 4** are allowed to overwrite this change of colour.

<b>0</b>	<b>NO CHANGE</b>	No change of colour
<b>1</b>	<b>CHANGE TO RED</b>	Colour of display changes to red
<b>2</b>	<b>CHANGE TO GREEN</b>	Colour of display changes to green
<b>3</b>	<b>CHANGE TO YELLOW</b>	Colour of display changes to yellow

## 6.12 Preselection 2 menu

The **Preselection 2** menu is only available for devices with order codes AVI, DO and RO. It allows to set the characteristics for **Preselection 2**.

### Source 2

This parameter sets the reference source for **Preselection 2**. For complete information please refer to the **Source 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

### Mode 2

Switching conditions for **Preselection 2**. The output / relay / display switches under the following conditions:

0 ... 5		For complete information on the switching conditions 0 ... 5, please refer to the <b>Mode 1</b> parameter in the "6.11 Preselection 1 menu" section on page 61.
6	RES>=PRES-TRAIL	Trailing <b>Preselection 2</b> : Display value is greater than or equal to <b>Preselection 1 – Preselection 2</b> <b>Preselection 2</b> is the trailing preselection from <b>Preselection 1</b> .

### Hysteresis 2

This parameter sets the switching hysteresis of the switch-off point for **Preselection 2** value. For complete information please refer to the **Hysteresis 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

### Pulse time 2 (s)

Duration of the output pulse for the switching condition of **Preselection 2** value. For complete information please refer to the **Pulse time 1 (s)** parameter in the "6.11 Preselection 1 menu" section on page 61.

### Output target 2

Assignment of an output or relay for the switching condition of **Preselection 2** value. For complete information please refer to the **Output target 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

### Output polarity 2

Polarity for the switching condition of **Preselection 2**. For complete information please refer to the **Output polarity 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

**Output lock 2**

Latch for the switching condition of **Preselection 2**. For complete information please refer to the **Output lock 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

**Start up delay 2 (s)**

Start up delay setting for the switching condition of **Preselection 2**. For complete information please refer to the **Start up delay 1 (s)** parameter in the "6.11 Preselection 1 menu" section on page 61.

**NOTE**

 **Start up delay 3 (s)** and **Start up delay 4 (s)** (see on pages 68 and 70 respectively) have an automatic start up delay setting.

**Event color 2**

Event-depending change of colour of the display for the switching condition of **Preselection 2**. **Event color 2**, **Event color 3** and **Event color 4** have the highest priority and are allowed to overwrite the change of colour set next to the **Event color 1** parameter. For complete information please refer to the **Event color 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

### 6.13 Preselection 3 menu

The **Preselection 3** menu is only available for devices with order codes AVI, DO and RO. It allows to set the characteristics for **Preselection 3**.

#### Source 3

This parameter sets the reference source for **Preselection 3**. For complete information please refer to the **Source 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

#### Mode 3

Switching conditions for **Preselection 3**. The output / relay / display switches under the following conditions:

0 ... 5		For complete information on the switching conditions 0 ... 5, please refer to the <b>Mode 1</b> parameter in the "6.11 Preselection 1 menu" section on page 61.
6 RES>=PRES-TRAIL		Trailing <b>Preselection 3</b> : Display value is greater than or equal to <b>Preselection 4 – Preselection 3</b> <b>Preselection 3</b> is the trailing preselection from <b>Preselection 4</b> .

#### Hysteresis 3

This parameter sets the switching hysteresis of the switch-off point for **Preselection 3** value. For complete information please refer to the **Hysteresis 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

#### Pulse time 3 (s)

Duration of the output pulse for the switching condition of **Preselection 3** value. For complete information please refer to the **Pulse time 1 (s)** parameter in the "6.11 Preselection 1 menu" section on page 61.

#### Output target 3

Assignment of an output or relay for the switching condition of **Preselection 3** value. For complete information please refer to the **Output target 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

#### Output polarity 3

Polarity for the switching condition of **Preselection 3**. For complete information please refer to the **Output polarity 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

**Output lock 3**

Latch for the switching condition of **Preselection 3**. For complete information please refer to the **Output lock 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

**Start up delay 3 (s)**

Start up delay setting for the switching condition of **Preselection 3**.

This adjustment only applies to the switching conditions 1 -  $|RESULT| \leq |PRES|$  and 4 -  $RESULT \leq PRES$  (see the **Mode 3** parameter on page 67).

<b>0</b>	<b>OFF</b>	No start up delay setting
<b>1</b>	<b>AUTO</b>	Automatic start up delay setting, until the preselection value / switching point is exceeded for the first time.

**NOTE**

**Start up delay 1 (s)** and **Start up delay 2 (s)** (see on pages 64 and 66 respectively) have a time-dependent start up delay setting.

**Event color 3**

Event-depending change of colour of the display for the switching condition of **Preselection 3**. **Event color 2**, **Event color 3** and **Event color 4** have the highest priority and are allowed to overwrite the change of colour set next to the **Event color 1** parameter. For complete information please refer to the **Event color 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

## 6.14 Preselection 4 menu

The **Preselection 4** menu is only available for devices with order codes AVI, DO and RO. It allows to set the characteristics for **Preselection 4**.

### Source 4

This parameter sets the reference source for **Preselection 4**. For complete information please refer to the **Source 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

### Mode 4

Switching conditions for **Preselection 4**. The output / relay / display switches under the following conditions:

0 ... 5		For complete information on the switching conditions 0 ... 5, please refer to the <b>Mode 1</b> parameter in the "6.11 Preselection 1 menu" section on page 61.
6	RES>=PRES-TRAIL	Trailing <b>Preselection 4</b> : Display value is greater than or equal to <b>Preselection 3 – Preselection 4</b> <b>Preselection 4</b> is the trailing preselection from <b>Preselection 3</b> .

### Hysteresis 4

This parameter sets the switching hysteresis of the switch-off point for **Preselection 4** value. For complete information please refer to the **Hysteresis 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

### Pulse time 4 (s)

Duration of the output pulse for the switching condition of **Preselection 4** value. For complete information please refer to the **Pulse time 1 (s)** parameter in the "6.11 Preselection 1 menu" section on page 61.

### Output target 4

Assignment of an output or relay for the switching condition of **Preselection 4** value. For complete information please refer to the **Output target 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

### Output polarity 4

Polarity for the switching condition of **Preselection 4**. For complete information please refer to the **Output polarity 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

**Output lock 4**

Latch for the switching condition of **Preselection 4**. For complete information please refer to the **Output lock 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

**Start up delay 4 (s)**

Start up delay setting for the switching condition of **Preselection 4**.

This adjustment only applies to the switching conditions **1 - |RESULT|<=|PRES|** and **4 - RESULT<=PRES** (see the **Mode 4** parameter on page 69).

<b>0</b>	<b>OFF</b>	No start up delay setting
<b>1</b>	<b>AUTO</b>	Automatic start up delay setting, until the preselection value / switching point is exceeded for the first time.

**NOTE**

**Start up delay 1 (s)** and **Start up delay 2 (s)** (see on pages 64 and 66 respectively) have a time-dependent start up delay setting.

**Event color 4**

Event-depending change of colour of the display for the switching condition of **Preselection 4**. **Event color 2**, **Event color 3** and **Event color 4** have the highest priority and are allowed to overwrite the change of colour set next to the **Event color 1** parameter. For complete information please refer to the **Event color 1** parameter in the "6.11 Preselection 1 menu" section on page 61.

### 6.15 Serial menu

The **Serial** menu allows to configure the basic settings of the serial interface (terminal blocks 16, 17 and 18). For complete information on the serial port features, please refer to the "4.8 Serial interface (-AVI- and -DO- order codes)" section on page 23.

This function is only available for devices with order codes AVI and DO.

#### Unit number

This parameter allows to set the address of the serial device. You can assign to the unit any address number between 11 and 99. The address must not contain any "0" because such numbers (20, 30, ...) are reserved for collective addressing (broadcast address).

11	Smallest address value
...	
99	Highest address value

#### Serial baud rate

This parameter allows to set the serial transmission speed (baud rate).

Available options are:

0	9600	9600 baud
1	19200	19200 baud
2	38400	38400 baud

#### Serial format

This parameter allows to set the bit data format.

		Data Bits	Parity Bit	Stop Bits
0	7-EVEN-1	7	even	1
1	7-EVEN-2	7	even	2
2	7-ODD-1	7	odd	1
3	7-ODD-2	7	odd	2
4	7-NONE-1	7	no	1
5	7-NONE-2	7	no	2
6	8-EVEN-1	8	even	1
7	8-ODD-1	8	odd	1
8	8-NONE-1	8	no	1
9	8-NONE-2	8	no	2

**Serial init**

This parameter allows to set the baud rate for the transmission of the initialization values to the OS6.0 software tool. If you set transmission values higher than 9600 baud, the duration of the initialization procedure will be shortened.

<b>0</b>	<b>NO</b>	The initialization values will be transmitted at 9600 baud. After initialization the unit will operate according to the user settings again.
<b>1</b>	<b>YES</b>	The initialization values will be transmitted according to the user defined baud rate ( <b>Serial baud rate</b> parameter). After initialization the unit will go on operating according to the user settings again.

**Serial protocol**

It sets the sequence of characters to be sent when using the serial output for cyclic data transmission under time control (see the **Serial timer (s)** parameter). If you set the option "1" the unit address is removed from the string, this results in a slightly faster transmission cycle.

The transmission string will be as follows:

Option 0

UN	UN	+ / -	X	X	X	X	X	X	LF	CR
----	----	-------	---	---	---	---	---	---	----	----

Option 1

+ / -	X	X	X	X	X	X	X	LF	CR
-------	---	---	---	---	---	---	---	----	----

Where:

UN UN = serial address, e.g. "1 1". See the **Unit number** parameter in the previous page (option **0** only)

+ / - = plus / minus signs, i.e. positive / negative sign of transmitted value

XXXXXXX = data to be transmitted according to the setting in the **Serial value** parameter

LF = line feed character

CR = carriage return character

<b>0</b>	Transmission string with serial address
<b>1</b>	Transmission string without serial address

**Serial timer (s)**

This parameter sets the cycle time for the cyclic transmission of data set in the **Serial value** parameter when using the serial output. The value is expressed in seconds. In case of a serial request, the cyclic transmission is stopped for 20 s.

00.000	Cyclic transmission is switched off. The unit will send data following a serial request or a "7 – Serial print" command (see the <b>Input 1 action</b> , <b>Input 2 action</b> and <b>Input 3 action</b> parameters on pages 77 and 79).
...	
60.000	Cycle time expressed in seconds.

**Serial value**

This parameter sets the value to be transmitted.

0	:0	Value of input 1
1	:1	Value of input 2
2	:2	Result of the combined operation of input 1 and input 2
3	:3	Result of the totalization 1
4	:4	Result of the totalization 2
5	:5	Result of the combined value of input 1 and input 2 with totalization
6	:6	Minimum value of input 1
7	:7	Maximum value of input 1
8	:8	Minimum value of input 2
9	:9	Maximum value of input 2

## 6.16 Analog OUT menu

The **Analog OUT** menu allows to configure the basic settings of the analogue output (terminal blocks 13 and 14 / 15).

For complete information on the analogue output features, please refer to the "4.7 Analogue output (-AVI- order code)" section on page 22.

This function is only available for devices with order code AVI.

### Analog source

This parameter set the reference source for the analogue output.

<b>0</b>	<b>INPUT 1</b>	The reference source is input 1.
<b>1</b>	<b>INPUT 2</b>	The reference source is input 2.
<b>2</b>	<b>LINKAGE 1_2</b>	The reference source is the result of the combined operation of input 1 and input 2.
<b>3</b>	<b>INPUT 1 TOTAL</b>	The reference source is input 1 with totalization.
<b>4</b>	<b>INPUT 2 TOTAL</b>	The reference source is input 2 with totalization.
<b>5</b>	<b>LINKAGE TOTAL</b>	The reference source is the result of the combined operation of input 1 and input 2 with totalization.
<b>6</b>	<b>N.A.</b>	Reserved
<b>7</b>	<b>N.A.</b>	Reserved
<b>8</b>	<b>MINIMUM VALUE 1</b>	Minimum value, the reference source is input 1.
<b>9</b>	<b>MAXIMUM VALUE 1</b>	Maximum value, the reference source is input 1.
<b>10</b>	<b>MINIMUM VALUE 2</b>	Minimum value, the reference source is input 2.
<b>11</b>	<b>MAXIMUM VALUE 2</b>	Maximum value, the reference source is input 2.

The totalization depends on the selected operational mode, see the table in the "6.5 IN 1 totalization menu" section on page 43. See also the **Operational mode** parameter on page 34.

### Analog format

This parameter sets the characteristics of the analogue output. The analogue output is proportional to the display value.

If **Analog format** is set to "**0 = -10...10V**", the polarity of the analogue output depends on the polarity of the display value.

<b>0</b>	<b>-10...10V</b>	-10 ... +10 V
<b>1</b>	<b>0...20MA</b>	0 ... 20 mA
<b>2</b>	<b>4...20MA</b>	4 ... 20 mA

### Analog start

This parameter sets the start value of the analogue conversion. The start value corresponds to the display value for an analogue output of 0 V or 0 mA or 4 mA depending on the set **Analog format**.

<b>-99999999</b>	Smallest start value
<b>+00000000</b>	Default value
<b>+99999999</b>	Highest start value

### Analog end

This parameter sets the end value of the analogue conversion. The end value corresponds to the display value for an analogue output of (+/-)10 V or 20 mA depending on the set **Analog format**.

<b>-99999999</b>	Smallest start value
<b>+00010000</b>	Default value
<b>+99999999</b>	Highest start value

### Analog gain (%)

This parameter sets the maximum conversion of the analogue output expressed in percentage (%).

<b>000.00</b>	Smallest gain
<b>100.00</b>	Default value
<b>110.00</b>	Highest gain



### EXAMPLE

If you set "102.00" next to this item the result will be a conversion of 10.2 V or 20.4 mA when the value set next to the **Analog end** parameter is reached.

If you set "95.00" next to this item the result will be a conversion of 9.5 V or 18 mA when the value set next to the **Analog end** parameter is reached.

#### Analog offset %

This parameter sets the zero offset of the analogue output.

<b>-99.99</b>	Smallest offset
<b>+00.00</b>	Default value
<b>+99.99</b>	Highest offset



#### EXAMPLE

If you set "+00.20" next to this item the result will be an offset of 0.02 V or 0.04 mA as regards the **Analog start** value.

## 6.17 Command menu

The **Command** menu allows to configure the operation of the inputs "10 - Ctrl. In 1", "11 - Ctrl. In 2" and "12 - Ctrl. In 3".

For complete information on the control inputs features, please refer to the "4.6 Control inputs" section on page 21.

### Input 1 action

This parameter sets the function of the input "10 - Ctrl. In 1".

0	NO	No function	
1	TARA INPUT 1	Value of input 1 is stored as an <b>Offset</b> of input 1	(d)
2	TARA INPUT 2	Value of input 2 is stored as an <b>Offset</b> of input 2	(d)
3	TARA INPUT 1+2	Value of input 1 is stored as an <b>Offset</b> of input 1 Value of input 2 is stored as an <b>Offset</b> of input 2	(d)
4	RESET TOTAL 1	Value of totalizer 1 is reset to zero	(d) (s)
5	RESET TOTAL 2	Value of totalizer 2 is reset to zero	(d) (s)
6	RESET TOTAL 1+2	Value of totalizer 1 is reset to zero Value of totalizer 2 is reset to zero	(d) (s)
7	TEACH PRESEL. 1	The value of <b>Source 1</b> (see on page 61) is stored as Preselection 1 (see the <b>Preselection 1</b> parameter on page 59).	(d)
8	TEACH PRESEL. 2	The value of <b>Source 2</b> (see on page 65) is stored as Preselection 2 (see the <b>Preselection 2</b> parameter on page 59).	(d)
9	TEACH PRESEL. 3	The value of <b>Source 3</b> (see on page 67) is stored as Preselection 3 (see the <b>Preselection 3</b> parameter on page 59).	(d)
10	TEACH PRESEL. 4	The value of <b>Source 4</b> (see on page 69) is stored as Preselection 4 (see the <b>Preselection 4</b> parameter on page 60).	(d)
11	SCROLL DISPLAY	It scrolls through the available display screens (see the "5.2 Screen structure during operation" section on page 27).	(d)
12	RESET MIN/MAX	It resets the min. / max. values.	(d) (s)
13	CLEAR LOOP TIME	N.A.	
14	ACTIVATE	N.A.	
15	STORE DATA	N.A.	
16	TESTPROGRAM	N.A.	

17	<b>SET RED COLOR</b>	The display lights up red. The colour can be changed by setting an event-dependent switching condition (see the parameters <b>Event color 1</b> , <b>Event color 2</b> , <b>Event color 3</b> and <b>Event color 4</b> in the "6.11 Preselection 1 menu" ... "6.14 Preselection 4 menu" on page 61 ff).	(d)
18	<b>SET GREEN COLOR</b>	The display lights up green. The colour can be changed by setting an event-dependent switching condition (see the parameters <b>Event color 1</b> , <b>Event color 2</b> , <b>Event color 3</b> and <b>Event color 4</b> in the "6.11 Preselection 1 menu" ... "6.14 Preselection 4 menu" on page 61 ff).	(d)
19	<b>SET YELLOW COLOR</b>	The display lights up yellow. The colour can be changed by setting an event-dependent switching condition (see the parameters <b>Event color 1</b> , <b>Event color 2</b> , <b>Event color 3</b> and <b>Event color 4</b> in the "6.11 Preselection 1 menu" ... "6.14 Preselection 4 menu" on page 61 ff).	(d)
20	<b>FREEZE</b>	It freezes the display value.	(s)
21	<b>KEY LOCK</b>	Key locked touch screen.	(s)
22	<b>LOCK RELEASE</b>	No latch for preselection.	(d)
23	<b>SERIAL PRINT</b>	It sends serial data, see the <b>Serial value</b> parameter on page 73.	(d)
24	<b>START PRESELECT</b>	N.A.	
25	<b>ADD TO TOTAL 1</b>	It adds the current value of input 1 to INPUT 1 TOTAL (see the parameters <b>Source 1</b> , <b>Source 2</b> , <b>Source 3</b> and <b>Source 4</b> in the "6.11 Preselection 1 menu" ... "6.14 Preselection 4 menu" on page 61 ff)	(d)
26	<b>ADD TO TOTAL 2</b>	It adds the current value of input 2 to INPUT 2 TOTAL (see the parameters <b>Source 1</b> , <b>Source 2</b> , <b>Source 3</b> and <b>Source 4</b> in the "6.11 Preselection 1 menu" ... "6.14 Preselection 4 menu" on page 61 ff)	(d)

(s) = static switching (level evaluation)

**Input 1 config.** parameter must be set to be active at LOW / HIGH level (see options 0 – ACTIVE LOW and 1 – ACTIVE HIGH).

(d) = dynamic switching (edge evaluation)

**Input 1 config.** parameter must be set to activate at rising / falling edge (see options 2 – RISING EDGE and 3 - FALLING EDGE).  
N.A. = not available

#### Input 1 config.

This parameter sets the switching characteristics of the input "10 - Ctrl. In 1".

<b>0</b>	<b>ACTIVE LOW</b>	It is active at "LOW" level (static)
<b>1</b>	<b>ACTIVE HIGH</b>	It is active at "HIGH" level (static)
<b>2</b>	<b>RISING EDGE</b>	It activates at rising edge
<b>3</b>	<b>FALLING EDGE</b>	It activates at falling edge

#### Input 2 action

This parameter sets the function of the input "11 - Ctrl. In 2". For complete information please refer to the **Input 1 action** parameter on page 77.

#### Input 2 config.

This parameter sets the switching characteristics of the input "11 - Ctrl. In 2". For complete information please refer to the **Input 1 config.** parameter on page 79.

#### Input 3 action

This parameter sets the function of the input "12 - Ctrl. In 3". For complete information please refer to the **Input 1 action** parameter on page 77.

#### Input 3 config.

This parameter sets the switching characteristics of the input "12 - Ctrl. In 3". For complete information please refer to the **Input 1 config.** parameter on page 79.

## 6.18 Display menu

The **Display** menu allows to set the features of the display.

Parameter changes become active only after exiting the menu selection.

### Start display

This parameter sets the display visualization after switching the device on.

0	SINGLE	The display shows one value in a single line (single source). The source must be set next to the following <b>Source single</b> parameter.
1	DUAL	The display shows two values in two separate lines (double source). The source must be set next to the <b>Source dual top</b> (first line) and <b>Source dual down</b> (second line) parameters below.

### Source single

It sets the reference source of the value to be displayed when the "single line" visualization mode is set (see the previous **Start display** parameter).

0	INPUT 1	The reference source is input 1.
1	INPUT 2	The reference source is input 2.
2	LINKAGE 1_2	The reference source is the result of the combined operation of input 1 and input 2.
3	INPUT 1 TOTAL	The reference source is input 1 with totalization.
4	INPUT 2 TOTAL	The reference source is input 2 with totalization.
5	LINKAGE TOTAL	The reference source is the result of the combined operation of input 1 and input 2 with totalization.
6	N.A.	Reserved
7	N.A.	Reserved
8	MINIMUM VALUE 1	Minimum value, the reference source is input 1.
9	MAXIMUM VALUE 1	Maximum value, the reference source is input 1.
10	MINIMUM VALUE 2	Minimum value, the reference source is input 2.
11	MAXIMUM VALUE 2	Maximum value, the reference source is input 2.

**Source dual top**

It sets the reference source of the value to be displayed in the first line when the "dual line" visualization mode is set (see the **Start display** parameter in the previous page).

<b>0</b>	<b>INPUT 1</b>	The reference source is input 1.
<b>1</b>	<b>INPUT 2</b>	The reference source is input 2.
<b>2</b>	<b>LINKAGE 1_2</b>	The reference source is the result of the combined operation of input 1 and input 2.
<b>3</b>	<b>INPUT 1 TOTAL</b>	The reference source is input 1 with totalization.
<b>4</b>	<b>INPUT 2 TOTAL</b>	The reference source is input 2 with totalization.
<b>5</b>	<b>LINKAGE TOTAL</b>	The reference source is the result of the combined operation of input 1 and input 2 with totalization.
<b>6</b>	<b>N.A.</b>	Reserved
<b>7</b>	<b>N.A.</b>	Reserved
<b>8</b>	<b>MINIMUM VALUE 1</b>	Minimum value, the reference source is input 1.
<b>9</b>	<b>MAXIMUM VALUE 1</b>	Maximum value, the reference source is input 1.
<b>10</b>	<b>MINIMUM VALUE 2</b>	Minimum value, the reference source is input 2.
<b>11</b>	<b>MAXIMUM VALUE 2</b>	Maximum value, the reference source is input 2.

**Source dual down**

It sets the reference source of the value to be displayed in the second line when the "dual line" visualization mode is set (see the **Start display** parameter in the previous page).

<b>0</b>	<b>INPUT 1</b>	The reference source is input 1.
<b>1</b>	<b>INPUT 2</b>	The reference source is input 2.
<b>2</b>	<b>LINKAGE 1_2</b>	The reference source is the result of the combined operation of input 1 and input 2.
<b>3</b>	<b>INPUT 1 TOTAL</b>	The reference source is input 1 with totalization.
<b>4</b>	<b>INPUT 2 TOTAL</b>	The reference source is input 2 with totalization.
<b>5</b>	<b>LINKAGE TOTAL</b>	The reference source is the result of the combined operation of input 1 and input 2 with totalization.
<b>6</b>	<b>N.A.</b>	Reserved
<b>7</b>	<b>N.A.</b>	Reserved
<b>8</b>	<b>MINIMUM VALUE</b>	Minimum value, the reference source is input 1.

	<b>1</b>	
<b>9</b>	<b>MAXIMUM VALUE 1</b>	Maximum value, the reference source is input 1.
<b>10</b>	<b>MINIMUM VALUE 2</b>	Minimum value, the reference source is input 2.
<b>11</b>	<b>MAXIMUM VALUE 2</b>	Maximum value, the reference source is input 2.

**Color**

This parameter sets the colour of the display.

It is also possible to enable an event-depending change of the colour of the display by setting a switching condition (see the parameters **Event color 1**, **Event color 2**, **Event color 3** and **Event color 4** in the "6.11 Preselection 1 menu" ... "6.14 Preselection 4 menu" on page 61 ff).

Event-depending changes are only available for devices with order codes AVI, DO and RO.

<b>0</b>	<b>RED</b>	The display is coloured in red
<b>1</b>	<b>GREEN</b>	The display is coloured in green
<b>2</b>	<b>YELLOW</b>	The display is coloured in yellow

**Brightness**

This parameter sets the brightness of the display expressed in percentage (%).

<b>010</b>	Min. brightness
<b>090</b>	Default value
<b>100</b>	Max. brightness

**Contrast**

This parameter sets the viewing angle.

<b>0</b>	Viewing angle from top
<b>1</b>	Viewing angle from centre
<b>2</b>	Viewing angle from bottom

**Screen saver**

This parameter sets the time expressed in seconds before the display is switched off, starting from the last touch action.

A new touch action will activate the display again.

<b>0000</b>	Screen saver not active
...	
<b>9999</b>	Longest time before the screen saver is activated

**Up-date-time**

This parameter sets the update time of the display (refresh of the display), the value is expressed in seconds. It does not affect the parameter values.

<b>0.005</b>	Shortest update time
<b>0.100</b>	Default value
<b>9.999</b>	Longest update time

**Font**

This parameter sets the font style.

<b>0</b>	Standard
<b>1</b>	Font 1

## 7 - Appendix

### 7.1 Data readout via serial interface

All codes shown in the **Serial value** parameter (see the "6.15 Serial menu" section on page 71) are available for serial readout by a PC or a PLC. For communication the monitors use the Drivecom Protocol according to ISO 1745. All protocol details can be found in the user's guide "MAN Serial Protocol IFxx\_LD25x\_LD30x I\_E.pdf". It is available for download from our web page [www.lika.biz](http://www.lika.biz).

To request for a data transmission you must send the following request string to the converter:

EOT	AD1	AD2	C1	C2	ENQ
-----	-----	-----	----	----	-----

EOT = control character CTRL D (Hex 04)

AD1 = unit address, High Byte

AD2 = unit address, Low Byte

C1 = register code, High Byte

C2 = register code, Low Byte

ENQ = control character CTRL E (Hex 05)



#### EXAMPLE

The following example shows the request string for readout of the serial code = 1 from a unit having address "11":

ASCII code:	EOT	1	1	:	1	ENQ
Hex code:	04	31	31	3A	31	05
Binary code:	0000 0100	0011 0001	0011 0001	0011 1010	0011 0001	0000 0101

Following a correct request, the unit will respond:

STX	C1	C2	xxxxx	ETX	BCC
-----	----	----	-------	-----	-----

STX = control character CTRL B (Hex 02)

C1 = register code, High Byte

C2 = register code, Low Byte

xxxxx = readout data

ETX = control character CTRL C (Hex 03)

BCC = block check character

## 8 – Parameters / serial codes

### 8.1 General menu

See the "6.2 General menu" section on page 34

Parameter	Serial code	Value	Min. value	Max. value	Default value
Operational mode	0	0	0	5	0
Pin preselection	1	0	0000	9999	0000
Pin parameter	2	0	0000	9999	0000
Back up memory	3	0	0	1	0
Factory settings	4	0	0	1	0
-	5	0	0	0	0
-	6	0	0	0	0
-	7	0	0	0	0
-	8	0	0	0	0

### 8.2 IN 1 properties menu

See the "6.3 IN 1 properties menu" section on page 36

Parameter	Serial code	Value	Min. value	Max. value	Default value
Configuration	9	0	0	2	0
Start value	10	0	-99999	+99999	+00000
End value	11	0	-99999	+99999	+10000
Decimal point	12	0	0	7	3
Scale units	13	0	0	29	0
Sampling time (s)	14	0	0.0010	60.000	00.010
Average filter	15	0	0	4	0
Offset	16	0	-99999	+99999	+00000
Linearization	17	0	0	2	0
Totalization	18	0	0	1	0
-	19	0	0	0	0
-	20	0	0	0	0
-	21	0	0	0	0

## 8.3 IN 1 linearization menu

See the "6.4 IN 1 linearization menu" section on page 40

Parameter	Serial code	Value	Min. value	Max. value	Default value
P1(X)	A0	0	-99999999	+99999999	+00000000
P1(Y)	A1	0	-99999999	+99999999	+00000000
P2(X)	A2	0	-99999999	+99999999	+00000000
P2(Y)	A3	0	-99999999	+99999999	+00000000
P3(X)	A4	0	-99999999	+99999999	+00000000
P3(Y)	A5	0	-99999999	+99999999	+00000000
P4(X)	A6	0	-99999999	+99999999	+00000000
P4(Y)	A7	0	-99999999	+99999999	+00000000
P5(X)	A8	0	-99999999	+99999999	+00000000
P5(Y)	A9	0	-99999999	+99999999	+00000000
P6(X)	B0	0	-99999999	+99999999	+00000000
P6(Y)	B1	0	-99999999	+99999999	+00000000
P7(X)	B2	0	-99999999	+99999999	+00000000
P7(Y)	B3	0	-99999999	+99999999	+00000000
P8(X)	B4	0	-99999999	+99999999	+00000000
P8(Y)	B5	0	-99999999	+99999999	+00000000
P9(X)	B6	0	-99999999	+99999999	+00000000
P9(Y)	B7	0	-99999999	+99999999	+00000000
P10(X)	B8	0	-99999999	+99999999	+00000000
P10(Y)	B9	0	-99999999	+99999999	+00000000
P11(X)	C0	0	-99999999	+99999999	+00000000
P11(Y)	C1	0	-99999999	+99999999	+00000000
P12(X)	C2	0	-99999999	+99999999	+00000000
P12(Y)	C3	0	-99999999	+99999999	+00000000
P13(X)	C4	0	-99999999	+99999999	+00000000
P13(Y)	C5	0	-99999999	+99999999	+00000000
P14(X)	C6	0	-99999999	+99999999	+00000000
P14(Y)	C7	0	-99999999	+99999999	+00000000
P15(X)	C8	0	-99999999	+99999999	+00000000
P15(Y)	C9	0	-99999999	+99999999	+00000000
P16(X)	D0	0	-99999999	+99999999	+00000000
P16(Y)	D1	0	-99999999	+99999999	+00000000
P17(X)	D2	0	-99999999	+99999999	+00000000
P17(Y)	D3	0	-99999999	+99999999	+00000000
P18(X)	D4	0	-99999999	+99999999	+00000000
P18(Y)	D5	0	-99999999	+99999999	+00000000

(continue on next page)

(continued)

Parameter	Serial code	Value	Min. value	Max. value	Default value
P19(X)	D6	0	-99999999	+99999999	+00000000
P19(Y)	D7	0	-99999999	+99999999	+00000000
P20(X)	D8	0	-99999999	+99999999	+00000000
P20(Y)	D9	0	-99999999	+99999999	+00000000
P21(X)	E0	0	-99999999	+99999999	+00000000
P21(Y)	E1	0	-99999999	+99999999	+00000000
P22(X)	E2	0	-99999999	+99999999	+00000000
P22(Y)	E3	0	-99999999	+99999999	+00000000
P23(X)	E4	0	-99999999	+99999999	+00000000
P23(Y)	E5	0	-99999999	+99999999	+00000000
P24(X)	E6	0	-99999999	+99999999	+00000000
P24(Y)	E7	0	-99999999	+99999999	+00000000

#### 8.4 IN 1 totalization menu

See the "6.5 IN 1 totalization menu" section on page 43

Parameter	Serial code	Value	Min. value	Max. value	Default value
Time base	E8	0	0	3	0
Divider	E9	0	0	3	0
Decimal point	F0	0	0	7	0
Scale units	F1	0	0	29	0
-	F2	0	0	0	0
-	F3	0	0	0	0
-	F4	0	0	0	0

## 8.5 IN 2 properties menu

See the "6.6 IN 2 properties menu" section on page 46

Parameter	Serial code	Value	Min. value	Max. value	Default value
Configuration	F5	0	0	2	0
Start value	F6	0	-99999	+99999	+00000
End value	F7	0	-99999	+99999	+10000
Decimal point	F8	0	0	7	3
Scale units	F9	0	0	29	0
Sampling time (s)	G0	0	0.0010	60.000	00.010
Average filter	G1	0	0	4	0
Offset	G2	0	-99999	+99999	+00000
Linearization	G3	0	0	2	0
Totalization	G4	0	0	1	0
-	G5	0	0	0	0
-	G6	0	0	0	0
-	G7	0	0	0	0

## 8.6 IN 2 linearization menu

See the "6.7 IN 2 linearization menu" section on page 50

Parameter	Serial code	Value	Min. value	Max. value	Default value
P1(X)	G8	0	-99999999	+99999999	+00000000
P1(Y)	G9	0	-99999999	+99999999	+00000000
P2(X)	H0	0	-99999999	+99999999	+00000000
P2(Y)	H1	0	-99999999	+99999999	+00000000
P3(X)	H2	0	-99999999	+99999999	+00000000
P3(Y)	H3	0	-99999999	+99999999	+00000000
P4(X)	H4	0	-99999999	+99999999	+00000000
P4(Y)	H5	0	-99999999	+99999999	+00000000
P5(X)	H6	0	-99999999	+99999999	+00000000
P5(Y)	H7	0	-99999999	+99999999	+00000000
P6(X)	H8	0	-99999999	+99999999	+00000000
P6(Y)	H9	0	-99999999	+99999999	+00000000
P7(X)	I0	0	-99999999	+99999999	+00000000
P7(Y)	I1	0	-99999999	+99999999	+00000000
P8(X)	I2	0	-99999999	+99999999	+00000000
P8(Y)	I3	0	-99999999	+99999999	+00000000

(continue on next page)

(continued)

Parameter	Serial code	Value	Min. value	Max. value	Default value
P9(X)	I4	0	-99999999	+99999999	+00000000
P9(Y)	I5	0	-99999999	+99999999	+00000000
P10(X)	I6	0	-99999999	+99999999	+00000000
P10(Y)	I7	0	-99999999	+99999999	+00000000
P11(X)	I8	0	-99999999	+99999999	+00000000
P11(Y)	I9	0	-99999999	+99999999	+00000000
P12(X)	J0	0	-99999999	+99999999	+00000000
P12(Y)	J1	0	-99999999	+99999999	+00000000
P13(X)	J2	0	-99999999	+99999999	+00000000
P13(Y)	J3	0	-99999999	+99999999	+00000000
P14(X)	J4	0	-99999999	+99999999	+00000000
P14(Y)	J5	0	-99999999	+99999999	+00000000
P15(X)	J6	0	-99999999	+99999999	+00000000
P15(Y)	J7	0	-99999999	+99999999	+00000000
P16(X)	J8	0	-99999999	+99999999	+00000000
P16(Y)	J9	0	-99999999	+99999999	+00000000
P17(X)	K0	0	-99999999	+99999999	+00000000
P17(Y)	K1	0	-99999999	+99999999	+00000000
P18(X)	K2	0	-99999999	+99999999	+00000000
P18(Y)	K3	0	-99999999	+99999999	+00000000
P19(X)	K4	0	-99999999	+99999999	+00000000
P19(Y)	K5	0	-99999999	+99999999	+00000000
P20(X)	K6	0	-99999999	+99999999	+00000000
P20(Y)	K7	0	-99999999	+99999999	+00000000
P21(X)	K8	0	-99999999	+99999999	+00000000
P21(Y)	K9	0	-99999999	+99999999	+00000000
P22(X)	L0	0	-99999999	+99999999	+00000000
P22(Y)	L1	0	-99999999	+99999999	+00000000
P23(X)	L2	0	-99999999	+99999999	+00000000
P23(Y)	L3	0	-99999999	+99999999	+00000000
P24(X)	L4	0	-99999999	+99999999	+00000000
P24(Y)	L5	0	-99999999	+99999999	+00000000

## 8.7 IN 2 totalization menu

See the "6.8 IN 2 totalization menu" section on page 53

Parameter	Serial code	Value	Min. value	Max. value	Default value
Time base	L6	0	0	3	0
Divider	L7	0	0	3	0
Decimal point	L8	0	0	7	0
Scale units	L9	0	0	29	0
-	M0	0	0	0	0
-	M1	0	0	0	0
-	M2	0	0	0	0

## 8.8 Linkage properties menu

See the "6.9 Linkage properties menu" section on page 56

Parameter	Serial code	Value	Min. value	Max. value	Default value
Factor	M3	0	-99999999	+99999999	+00000001
Divider	M4	0	-99999999	+99999999	+00000001
Additive value	M5	0	-99999999	+99999999	+00000000
Decimal point	M6	0	0	7	0
Scale units	M7	0	0	29	0
-	M8	0	0	0	0
-	M9	0	0	0	0
-	N0	0	0	0	0

## 8.9 Preselection values menu

See the "6.10 Preselection values menu" section on page 59

Parameter	Serial code	Value	Min. value	Max. value	Default value
Preselection 1	05	1000	-99999999	+99999999	+00001000
Preselection 2	06	2000	-99999999	+99999999	+00002000
Preselection 3	07	3000	-99999999	+99999999	+00003000
Preselection 4	08	4000	-99999999	+99999999	+00004000
-	09	0	0	0	0
-	P0	0	0	0	0

## 8.10 Preselection 1 menu

See the "6.11 Preselection 1 menu" section on page 61

Parameter	Serial code	Value	Min. value	Max. value	Default value
Source 1	P1	0	0	11	0
Mode 1	P2	0	0	6	0
Hysteresis 1	P3	0	00000	99999	00000
Pulse time 1 (s)	P4	0	00.000	60.000	00.000
Output target 1	P5	0	0	6	1
Output polarity 1	P6	0	0	1	0
Output lock 1	P7	0	0	1	0
Start up delay 1 (s)	P8	0	00.000	60.000	00.000
Event color 1	P9	0	0	3	0
-	Q0	0	0	0	0
-	Q1	0	0	0	0

## 8.11 Preselection 2 menu

See the "6.12 Preselection 2 menu" section on page 65

Parameter	Serial code	Value	Min. value	Max. value	Default value
Source 2	Q2	0	0	11	0
Mode 2	Q3	0	0	6	0
Hysteresis 2	Q4	0	00000	99999	00000
Pulse time 2 (s)	Q5	0	00.000	60.000	00.000
Output target 2	Q6	0	0	6	1
Output polarity 2	Q7	0	0	1	0
Output lock 2	Q8	0	0	1	0
Start up delay 2 (s)	Q9	0	00.000	60.000	00.000
Event color 2	R0	0	0	3	0
-	R1	0	0	0	0
-	R2	0	0	0	0

## 8.12 Preselection 3 menu

See the "6.13 Preselection 3 menu" section on page 67

Parameter	Serial code	Value	Min. value	Max. value	Default value
Source 3	R3	0	0	11	0
Mode 3	R4	0	0	6	0
Hysteresis 3	R5	0	00000	99999	00000
Pulse time 3 (s)	R6	0	00.000	60.000	00.000
Output target 3	R7	0	0	6	1
Output polarity 3	R8	0	0	1	0
Output lock 3	R9	0	0	1	0
Start up delay 3 (s)	S0	0	0	1	0
Event color 3	90	0	0	3	0
-	91	0	0	0	0
-	92	0	0	0	0

## 8.13 Preselection 4 menu

See the "6.14 Preselection 4 menu" section on page 69

Parameter	Serial code	Value	Min. value	Max. value	Default value
Source 4	9~	0	0	11	0
Mode 4	S1	0	0	6	0
Hysteresis 4	S2	0	00000	99999	00000
Pulse time 4 (s)	S3	0	00.000	60.000	00.000
Output target 4	S4	0	0	6	1
Output polarity 4	S5	0	0	1	0
Output lock 4	S6	0	0	1	0
Start up delay 4 (s)	S7	0	0	1	0
Event color 4	S8	0	0	3	0
-	S9	0	0	0	0
-	T0	0	0	0	0

## 8.14 Serial menu

See the "6.15 Serial menu" section on page 71

Parameter	Serial code	Value	Min. value	Max. value	Default value
Unit number	T1	0	11	99	11
Serial baud rate	T2	0	0	2	0
Serial format	T3	0	0	9	0
Serial init	T4	0	0	1	0
Serial protocol	T5	0	0	1	0
Serial timer (s)	T6	0	00.000	60.000	00.000
Serial value	T7	0	0	9	0
-	T8	0	0	0	0
-	T9	0	0	0	0

## 8.15 Analog menu

See the "6.16 Analog OUT menu" section on page 74

Parameter	Serial code	Value	Min. value	Max. value	Default value
Analog source	U0	0	0	11	0
Analog format	U1	0	0	2	0
Analog start	U2	0	-99999999	99999999	+00000000
Analog end	U3	0	-99999999	99999999	+0010000
Analog gain (%)	U4	0	000.00	110.00	100.00
Analog offset %	U5	0	-99.99	+99.99	+00.00
-	U6	0	0	0	0
-	U7	0	0	0	0

## 8.16 Command menu

See the "6.17 Command menu" section on page 77

Parameter	Serial code	Value	Min. value	Max. value	Default value
Input 1 action	U8	0	0	26	0
Input 1 config.	U9	0	0	3	2
Input 2 action	V0	0	0	26	0
Input 2 config.	V1	0	0	3	2
Input 3 action	V2	0	0	26	0
Input 3 config.	V3	0	0	3	2
-	V4	0	0	0	0
-	V5	0	0	0	0
-	V6	0	0	0	0
-	V7	0	0	0	0

## 8.17 Display menu

See the "6.18 Display menu" section on page 80

Parameter	Serial code	Value	Min. value	Max. value	Default value
Start display	V8	0	0	1	0
Source single	V9	0	0	11	0
Source dual top	W0	0	0	11	0
Source dual down	W1	0	0	11	1
Color	W2	0	0	2	0
Brightness	W3	0	010	100	090
Contrast	W4	0	0	2	1
Screen saver	W5	0	0000	9999	0000
Up-date-time	W6	0	0.005	9.999	0.100
Font	W7	0	0	1	0
-	W8	0	0	0	0
-	W9	0	0	0	0
-	X0	0	0	0	0

**8.18 Serial codes of commands**

Serial code	Command
54	TARA INPUT 1
55	TARA INPUT 2
56	TARA INPUT 1 + 2
57	RESET TOTAL 1
58	RESET TOTAL 2
59	RESET TOTAL 1 + 2
60	TEACH PRESELECTION 1
61	TEACH PRESELECTION 2
62	TEACH PRESELECTION 3
63	TEACH PRESELECTION 4
64	SCROLL DISPLAY
65	RESET MIN. / MAX.
66	CLEAR LOOP TIME
67	ACTIVATE
68	STORE DATA
69	TESTPROGRAM

Document release	Release date	Description
1.0	02.10.2018	First issue
1.1	29.03.2019	RS-485 information added
1.2	07.05.2019	Mode 1 and Start up delay 1 (s) items updated in all Preselection menus



Dispose separately

# lika

Lika Electronic  
Via S. Lorenzo, 25 • 36010 Carrè (VI) • Italy

Tel. +39 0445 806600  
Fax +39 0445 806699



info@lika.biz • www.lika.biz